




USER INSTRUCTIONS

Flowserve R and RX

Centrifugal Rubber Lined Slurry Pump

PCN = 71569242 21-05
Original instructions

Installation Operation Maintenance



These instructions must be read prior to installing, operating, using, and maintaining this equipment.

CONTENTS

	PAGE		
1 INTRODUCTION AND SAFETY	4	6.7 Renewal clearances	36
1.1 General	4	6.8 Disassembly	36
1.2 CE marking and approvals.....	4	6.9 Examination of parts.....	38
1.3 Disclaimer	4	6.10 Assembly	38
1.4 Copyright.....	4	6.11 Impeller axial clearance adjustment	45
1.5 Duty conditions.....	4	6.12 Liner Mismatch	47
1.6 Safety	5	7 FAULTS; CAUSES AND REMEDIES	48
1.7 Safety labels summary.....	9	8 PARTS LIST AND DRAWINGS	51
1.8 Specific machine performance.....	10	8.1 Frame 0 – 1.25R090.....	51
1.9 Noise level.....	10	8.2 R Pump - Frames 1&2.....	52
2 TRANSPORT AND STORAGE	11	8.3 RX - Frames 1&2.....	53
2.1 Consignment receipt and unpacking.....	11	8.4 R pump - Frame 3&4	54
2.2 Handling	11	8.6 General arrangement drawing.....	56
2.3 Lifting.....	11	9 CERTIFICATION	56
2.4 Storage	11	10 OTHER RELEVANT DOCUMENTATION AND	
2.5 Recycling and end of product life.....	12	MANUALS	56
3 PUMP DESCRIPTION.....	12	10.1 Supplementary User Instruction manuals	56
3.1 Configurations	12	10.2 Change notes	56
3.2 Name nomenclature.....	12	10.3 Additional sources of information	56
3.3 Design of major parts	13		
3.4 Performance and operating limits	13		
3.5 Materials Of Construction	15		
3.6 Tables of Engineering Data	16		
4.1 Location.....	20		
4.2 Part assemblies.....	20		
4.3 Foundation	20		
4.4 Baseplate installation	20		
4.5 Initial alignment	21		
4.6 Grouting	23		
4.7 Piping	23		
4.8 Final shaft alignment check	27		
4.9 Electrical connections	27		
4.10 Protection systems.....	28		
5 COMMISSIONING, START-UP, OPERATION AND			
SHUTDOWN	28		
5.1 Pre-commissioning procedure	28		
5.2 Pump lubricants	29		
5.3 Direction of rotation.....	30		
5.4 Guarding	30		
5.5 Priming and auxiliary supplies	30		
5.6 Starting the pump.....	30		
5.7 Operating the pump	31		
5.8 Stopping and shutdown	32		
5.9 Hydraulic, mechanical and electrical duty.....	32		
6 MAINTENANCE.....	33		
6.1 General	33		
6.2 Maintenance schedule	33		
6.3 Spare parts.....	35		
6.4 Recommended spares and consumable items.....	35		
6.5 Tools required	35		
6.6 Fastener torques	36		

INDEX

	PAGE
Alignment of shafting (see 4.5, 4.7 and 4.3).....	20
CE marking and approvals (1.2).....	4
Clearances (see 6.7, Renewal clearances).....	34
Clearance setting (6.11)	43
Commissioning and operation (see 5).....	27
Configurations (3.1)	12
Direction of rotation (5.3)	29
Dismantling (see 6.8, Disassembly)	35
Duty conditions (1.5).....	4
Electrical connections (4.8)	15
Examination of parts (6.9).....	25
Faults; causes and remedies.....	47
General assembly drawings (see 8).....	50
Grouting (4.4).....	21
Guarding (5.4).....	29
Handling (2.2)	9
Hydraulic, mechanical and electrical duty (5.9).....	31
Lifting (2.3).....	11
Location (4.1).....	21
Lubrication schedule (see 5.2, Pump lubricants)	28
Maintenance schedule (6.2)	32
Piping (4.7)	22
Priming and auxiliary supplies (5.5).....	29
Reassembly (see 6.10, Assembly)	37
Replacement parts (see 6.3 and 6.4)	32
Safety, electrical (see 4.9)	26
Safety, protection systems (see 1.6)	5
Sound level (see 1.9, Noise level)	8
Specific machine performance (1.8).....	8
Starting the pump (5.6).....	29
Stopping and shutdown (5.8).....	31
Storage (2.4).....	9
Supplementary manuals or information sources	55
Tools required (6.5)	34
Torques for fasteners (6.6)	34

1 INTRODUCTION AND SAFETY

1.1 General



These instructions must always be kept close to the product's operating location or directly with the product.

Flowserve products are designed, developed and manufactured with state-of-the-art technologies in modern facilities. The unit is produced with great care and commitment to continuous quality control, utilizing sophisticated quality techniques, and safety requirements.

Flowserve is committed to continuous quality improvement and being at service for any further information about the product in its installation and operation or about its support products, repair and diagnostic services.

These instructions are intended to facilitate familiarization with the product and its permitted use. Operating the product in compliance with these instructions is important to help ensure reliability in service and avoid risks. The instructions may not take into account local regulations; ensure such regulations are observed by all, including those installing the product. Always coordinate repair activity with operations personnel, and follow all plant safety requirements and applicable safety and health laws and regulations.



These instructions must be read prior to installing, operating, using and maintaining the equipment in any region worldwide. The equipment must not be put into service until all the conditions relating to safety noted in the instructions, have been met. Failure to follow and apply the present user instructions is considered to be misuse. Personal injury, product damage, delay or failure caused by misuse are not covered by the Flowserve warranty.

1.2 CE marking and approvals

It is a legal requirement that machinery and equipment put into service within certain regions of the world shall conform with the applicable CE Marking Directives covering Machinery and, where applicable, Low Voltage Equipment, Electromagnetic Compatibility (EMC), Pressure Equipment Directive (PED) and Equipment for Potentially Explosive Atmospheres (ATEX).

Where applicable the Directives and any additional Approvals cover important safety aspects relating to machinery and equipment and the satisfactory provision

of technical documents and safety instructions. Where applicable this document incorporates information relevant to these Directives and Approvals.

To confirm the Approvals applying and if the product is CE marked, check the serial number plate markings and the Certification. (See section 9, *Certification*.)

1.3 Disclaimer

Information in these User Instructions is believed to be complete and reliable. However, in spite of all of the efforts of Flowserve Corporation to provide comprehensive instructions, good engineering and safety practice should always be used.

Flowserve manufactures products to exacting International Quality Management System Standards as certified and audited by external Quality Assurance organizations. Genuine parts and accessories have been designed, tested and incorporated into the products to help ensure their continued product quality and performance in use. As Flowserve cannot test parts and accessories sourced from other vendors the incorrect incorporation of such parts and accessories may adversely affect the performance and safety features of the products. The failure to properly select, install or use authorized Flowserve parts and accessories is considered to be misuse. Damage or failure caused by misuse is not covered by the Flowserve warranty. In addition, any modification of Flowserve products or removal of original components may impair the safety of these products in their use.

1.4 Copyright

All rights reserved. No part of these instructions may be reproduced, stored in a retrieval system or transmitted in any form or by any means without prior permission of Flowserve.

1.5 Duty conditions

This product has been selected to meet the specifications of your purchaser order. The acknowledgement of these conditions has been sent separately to the Purchaser. A copy should be kept with these instructions.



The product must not be operated beyond the parameters specified for the application. If there is any doubt as to the suitability of the product for the application intended, contact Flowserve for advice, quoting the serial number.


If the conditions of service on your purchase order are going to be changed (for example liquid pumped,


temperature or duty) it is requested that the user seeks the written agreement of Flowserve before start up.


1.6 Safety


1.6.1 Summary of safety markings


These User Instructions contain specific safety markings where non-observance of an instruction would cause hazards. The specific safety markings are:


 **DANGER** This symbol indicates electrical safety instructions where non-compliance will involve a high risk to personal safety or the loss of life.

 This symbol indicates safety instructions where non-compliance would affect personal safety and could result in loss of life.

 This symbol indicates "hazardous and toxic fluid" safety instructions where non-compliance would affect personal safety and could result in loss of life.

 This symbol indicates safety instructions where non-compliance will involve some risk to safe operation and personal safety and would damage the equipment or property.

 This symbol indicates explosive atmosphere zone marking according to ATEX. It is used in safety instructions where non-compliance in the hazardous area would cause the risk of an explosion.

 This symbol is used in safety instructions to remind not to rub non-metallic surfaces with a dry cloth; ensure the cloth is damp. It is used in safety instructions where non-compliance in the hazardous area would cause the risk of an explosion.

Note: This sign is not a safety symbol but indicates an important instruction in the assembly process.


1.6.2 Personnel qualification and training

All personnel involved in the operation, installation, inspection and maintenance of the unit must be qualified to carry out the work involved. If the personnel in question do not already possess the necessary knowledge and skill, appropriate training and instruction must be provided. If required, the operator may commission the manufacturer/supplier to provide applicable training.

Always coordinate repair activity with operations and health and safety personnel, and follow all plant safety requirements and applicable safety and health laws and regulations.

1.6.3 Safety action


This is a summary of conditions and actions to prevent injury to personnel and damage to the environment and to equipment. For products used in potentially explosive atmospheres section 1.6.4 also applies.


 **DANGER** NEVER DO MAINTENANCE WORK WHEN THE UNIT IS CONNECTED TO POWER


 **GUARDS MUST NOT BE REMOVED WHILE THE PUMP IS OPERATIONAL**

 **DRAIN THE PUMP AND ISOLATE PIPEWORK BEFORE DISMANTLING THE PUMP**


The appropriate safety precautions should be taken where the pumped liquids are hazardous.

 **FLUORO-ELASTOMERS (When fitted.)**
When a pump has experienced temperatures over 250 °C (482 °F), partial decomposition of fluoro-elastomers (example: Viton) will occur. In this condition these are extremely dangerous and skin contact must be avoided.

 **HANDLING COMPONENTS**
Many precision parts have sharp corners and the wearing of appropriate safety gloves and equipment is required when handling these components. To lift heavy pieces above 25 kg (55 lb) use a crane appropriate for the mass and in accordance with current local regulations.

 **THERMAL SHOCK**
Rapid changes in the temperature of the liquid within the pump can cause thermal shock, which can result in damage or breakage of components and should be avoided.

 **NEVER APPLY HEAT TO REMOVE IMPELLER**
Trapped lubricant or vapour could cause an explosion.

 **HOT (and cold) PARTS**
If hot or freezing components or auxiliary heating supplies can present a danger to operators and persons entering the immediate area, action must be taken to avoid accidental contact. If complete protection is not possible, the machine access must be limited to maintenance staff only, with clear visual warnings and indicators to those entering the immediate area. Note: bearing housings must not be insulated and drive motors and bearings may be hot.

If the temperature is greater than 80°C (176 °F) or below - 5 °C (23 °F) in a restricted zone, or exceeds local regulations, action as above shall be taken.



HAZARDOUS LIQUIDS

When the pump is handling hazardous liquids care must be taken to avoid exposure to the liquid by appropriate siting of the pump, limiting personnel access and by operator training. If the liquid is flammable and/or explosive, strict safety procedures must be applied.

Gland packing must not be used when pumping hazardous liquids.



CAUTION

PREVENT EXCESSIVE EXTERNAL PIPE LOAD

Do not use pump as a support for piping. Do not mount expansion joints, unless allowed by Flowserve in writing, so that their force, due to internal pressure, acts on the pump flange.



CAUTION

NEVER RUN THE PUMP DRY



CAUTION

ENSURE CORRECT LUBRICATION

(See section 5, *Commissioning, startup, operation and shutdown.*)



CAUTION

START THE PUMP WITH OUTLET VALVE PART OPENED

(Unless otherwise instructed at a specific point in the user instructions.)


This is recommended to minimize the risk of overloading and damaging the pump motor at full or zero flow. Pumps may be started with the valve further open only on installations where this situation cannot occur. The pump outlet control valve may need to be adjusted to comply with the duty following the run-up process. (See section 5, *Commissioning start-up, operation and shutdown.*)



CAUTION

INLET VALVES TO BE FULLY OPEN WHEN PUMP IS RUNNING

Running the pump at zero flow or below the recommended minimum flow continuously will cause damage to the seal.



CAUTION

DO NOT RUN THE PUMP AT ABNORMALLY HIGH OR LOW FLOW RATES

Operating at a flow rate higher than normal or at a flow rate with no back pressure on the pump may overload the motor and cause cavitation. Low flow rates may cause a reduction in pump/bearing life, overheating of the pump, instability and cavitation/ vibration.

1.6.4 Products used in potentially explosive atmospheres



Measures are required to:

- Avoid excess temperature
- Prevent build up of explosive mixtures
- Prevent the generation of sparks
- Prevent leakages
- Maintain the pump to avoid hazard

The following instructions for pumps and pump units when installed in potentially explosive atmospheres must be followed to help ensure explosion protection. For ATEX, both electrical and non-electrical equipment must meet the requirements of European Directive 2014/34/EU. Always observe the regional legal Ex requirements; Ex electrical items outside the EU may be required certified to other than ATEX (example: IECEx, UL).

1.6.4.1 Scope of compliance




Use equipment only in the zone for which it is appropriate. Always check that the driver, drive coupling assembly, seal and pump equipment are suitably rated and/or certified for the classification of the specific atmosphere in which they are to be installed.

Where Flowserve has supplied only the bare shaft pump, the Ex rating applies only to the pump. The party responsible for assembling the ATEX pump set shall select the coupling, driver and any additional equipment, with the necessary CE Certificate/ Declaration of Conformity establishing it is suitable for the area in which it is to be installed.

The output from a variable frequency drive (VFD) can cause additional heating affects in the motor and so, for pumps sets with a VFD, the ATEX Certification for the motor must state that it covers the situation where electrical supply is from the VFD. This particular requirement still applies even if the VFD is in a safe area.

1.6.4.2 **Marking**

An example of ATEX equipment marking is shown below. The actual classification of the pump will be engraved on the nameplate.



1.6.4.3 **Avoiding excessive surface temperatures**

ENSURE THE EQUIPMENT TEMPERATURE CLASS IS SUITABLE FOR THE HAZARD ZONE

Pumps have a temperature class as stated in the ATEX Ex rating on the nameplate. These are based on a maximum ambient of 40 °C (104 °F); refer to Flowserve for higher ambient temperatures.

The surface temperature on the pump is influenced by the temperature of the liquid handled. The maximum permissible liquid temperature depends on the temperature class and must not exceed the values in the table that follows.

Maximum permitted liquid temperature for pumps

Temperature class to EN ISO 80079-36	Maximum surface temperature permitted	Temperature limit of liquid handled
T6	85 °C (185 °F)	Consult Flowserve
T5	100 °C (212 °F)	Consult Flowserve
T4	135 °C (275 °F)	115 °C (239 °F) *
T3	200 °C (392 °F)	180 °C (356 °F) *
T2	300 °C (572 °F)	275 °C (527 °F) *

T1	450 °C (842 °F)	400 °C (752 °F) *
----	-----------------	-------------------

The temperature rise at the seals and bearings and due to the minimum permitted flow rate is taken into account in the temperatures stated.

The operator is responsible to ensure that the specified maximum liquid temperature is not exceeded.

Temperature classification “Tx” is used when the liquid temperature varies and when the pump is required to be used in differently classified potentially explosive atmospheres. In this case the user is responsible for ensuring that the pump surface temperature does not exceed that permitted in its actual installed location.

If an explosive atmosphere exists during the installation, do not attempt to check the direction of rotation by starting the pump unfilled. Even a short run time may give a high temperature resulting from contact between rotating and stationary components.

Avoid mechanical, hydraulic or electrical overload by using motor overload trips, temperature monitor or a power monitor and make routine vibration monitoring checks.

In dirty or dusty environments, regular checks must be made and dirt removed from areas around close clearances, bearing housings and motors.

Where there is any risk of the pump being run against a closed valve generating high liquid and casing external surface temperatures fit an external surface temperature protection device.

1.6.4.4 **Preventing the build up of explosive mixtures**

ENSURE THE PUMP IS PROPERLY FILLED AND VENTED AND DOES NOT RUN DRY

Ensure the pump and relevant suction and discharge pipeline system is totally filled with liquid at all times during the pump operation, so that an explosive atmosphere is prevented. In addition, it is essential to make sure that seal chambers, auxiliary shaft seal systems and any heating and cooling systems are properly filled.

If the operation of the system cannot avoid this condition install an appropriate dry run protection device (for example liquid detection or a power monitor).

To avoid potential hazards from fugitive emissions of vapour or gas to atmosphere, the surrounding area must be well ventilated.

1.6.4.5 **Preventing sparks**



To prevent a potential hazard from mechanical contact, the coupling guard must be non-sparking.

To avoid the potential hazard from random induced current generating a spark, the baseplate must be properly grounded.



Make sure that the connection between pump and baseplate is electrically conductive.



Avoid electrostatic charge: do not rub non-metallic surfaces with a dry cloth; ensure cloth is damp.

For ATEX, the coupling must be selected to comply with 2014/34/EU and correct alignment must be maintained.

Additional requirement for metallic pumps on non-metallic baseplates.

When metallic components are fitted on a non-metallic baseplate they must be individually grounded.

1.6.4.6 **Preventing leakage**



The pump must only be used to handle liquids for which it has been approved to have the correct corrosion resistance.

Avoid entrapment of liquid in the pump and associated piping due to closing of suction and discharge valves, which could cause dangerous excessive pressures to occur if there is heat input to the liquid. This can occur if the pump is stationary or running.

Bursting of liquid containing parts due to freezing must be avoided by draining or protecting the pump and ancillary systems.

Where there is the potential hazard of a loss of a seal barrier fluid or external flush, the fluid must be monitored.

If leakage of liquid to atmosphere can result in a hazard, install a liquid detection device.

1.6.4.7 **Maintenance to avoid the hazard**



CORRECT MAINTENANCE IS REQUIRED TO AVOID POTENTIAL HAZARDS WHICH GIVE A RISK OF EXPLOSION

The responsibility for compliance with maintenance instructions is with the plant operator.

To avoid potential explosion hazards during maintenance, the tools, cleaning and painting materials used must not give rise to sparking or adversely affect the ambient conditions. Where there is a risk from such tools or materials, maintenance must be conducted in a safe area.


It is recommended that a maintenance plan and schedule is adopted. (See section 6, *Maintenance*.)

1.7 Safety labels summary


1.7.1 Nameplate

For details of nameplate, see the *Declaration of Conformity*, or separate documentation included with these User Instructions.


1.7.2 Safety labels



MECHANICAL SEAL WARNING
P/N 2113931-001




ROTATION WARNING
P/N 2113932-001



GROUT WARNING
P/N 2113934-001



LIFTING WARNING
P/N 9901701-001



LUBRICATION WARNING – QF-440-R01 (2124841)

Oil lubricated units only:

1.8 Specific machine performance

For performance parameters see section 1.5, *Duty conditions*. When the contract requirement specifies these to be incorporated into User Instructions these are included here. Where performance data has been supplied separately to the purchaser these should be obtained and retained with these User Instructions if required.

1.9 Noise level

When pump noise level exceeds 85 dBA attention must be given to prevailing Health and Safety Legislation, to limit the exposure of plant operating personnel to the noise. The usual approach is to control exposure time to the noise or to enclose the machine to reduce emitted sound. You may have already specified a limiting noise level when the equipment was ordered, however if no noise requirements were defined then machines above a certain power level will exceed 85 dBA. In such situations, consideration must be given to the fitting of an acoustic enclosure to meet local regulations.

Pump noise level is dependent on a number of factors, the type of motor fitted, the operating capacity, pipework design and acoustic characteristics of the

building. The levels specified in the table below are estimated and not guaranteed.

The dBA values are based on the noisiest ungeared electric motors that are likely to be encountered. They are Sound Pressure levels at 1 m (3.3 ft) from the directly driven pump, for "free field over a reflecting plane". For estimating L_{wA} sound power level (re 1 pW) add 14dBA to the sound pressure value.

If a pump unit only has been purchased, for fitting with your own driver, then the "pump only" noise levels from the table should be combined with the level for the driver obtained from the supplier. If the motor is driven by an inverter, it may show an increase in noise level at some speeds. Consult a Noise Specialist for the combined calculation.



For units driven by equipment other than electric motors or units contained within enclosures, see the accompanying information sheets and manuals.

R and RX Slurry pump size	Noise Level dBA (at 1 m (3 ft) reference 20 µPa)	Pump speed rpm	Sound Power Level dBA
1.25R090	74	2000	88
2.5 R091	75	2250	89
3 R091	75	2250	89
3 R111	77	2000	91
4 R122	80	1780	94
5 R142	80	1600	94
6 R163	81	1350	95
8 R193	82	1180	96
10R234	83	1000	97
12R264	83	880	97
18R416	86	1180	100

2 TRANSPORT AND STORAGE

2.1 Consignment receipt and unpacking

Immediately after receipt of the equipment it must be checked against the delivery and shipping documents for its completeness and that there has been no damage in transportation. Any shortage and or damage must be reported immediately to Flowserve and received in writing within one month of receipt of the equipment. Later claims cannot be accepted.

Check any crates, boxes and wrappings for any accessories or spare parts which may be packed separately with the equipment or attached to side walls of the box or equipment.


Each product has a unique serial number. Check that this number corresponds with that advised and always quote this number in correspondence as well as when ordering spare parts or further accessories.

2.2 Handling

Boxes, crates, pallets or cartons may be unloaded using fork-lift vehicles or slings dependent on their size and construction.

The pump should be lifted with suitably sized and located slings. Do not use the shaft for lifting and take special care to prevent the pump from rotating in the slings due to unbalanced weight distribution.


2.3 Lifting



A crane must be used for all pump sets or components in excess of 25 kg (55 lb). Fully trained personnel must carry out lifting, in accordance with local regulations. The driver and pump weights are recorded on the general arrangement drawing for the specific project. The table of engineering data in section 3.5 is for bare pump only and does not include the weight of the base, driver or auxiliary equipment.

The pump unit should be lifted as shown. Do not Use the driver, bare shaft pump or component lifting points to lift the complete machine.

Before lifting the driver alone, refer to the manufacturer's instructions



2.4 Storage



2.4.1 Short-Term Storage

When it is necessary to store a pump for a short time before it can be installed, place it in a dry, cool location. Protect it thoroughly from moisture and condensation. Protective flange covers should not be removed until the pump is being installed.

Wrap the exposed portions of the shaft and coupling to protect against sand, grit or other foreign matter. Oil lubricated units should be lubricated (refer to Section III) to protect the bearings. Grease lubricated units are lubricated at the factory during assembly. Turn the rotor over by hand at least once a week to maintain a protective film on the bearing components.

2.4.2 Long Term Storage

More than precautions are required if long-term storage in excess of 90 days from factory shipment is unavoidable.



The internal surfaces of the pump must not be sprayed with oil or rust preventative as it may damage the rubber lining and impeller.

Suspend bags of desiccant material inside the casing and completely seal all openings from the surrounding atmosphere. The stuffing box should be packed with clean, dry rags. Use of this method requires that the casing be initially free of liquid. The desiccant material should be checked at regular intervals to ensure that it has not absorbed excessive water vapour. A warning instruction, advising that the desiccant must be removed prior to installation should be wired to the pump.

A rust inhibitor should be added to the lubricating oil of oil lubricated units to give additional protection without destroying the lubricating properties of the oil. For specific recommendations, consult your lubrication dealer. Grease lubricated units, which can be identified by the grease fitting at each bearing location, should be well lubricated prior to placing in storage. Small amounts of additional grease should be added at regular intervals during storage. Refer to Section III for additional information related to grease lubrication.

Storage of pumps in areas of high ambient vibration should be avoided to prevent bearing damage due to brinelling. The risk of such damage can be reduced by frequent rotation of the shaft.

The pump half coupling and key should be removed from the shaft, coated with rust preventative and wrapped to prevent metal-to-metal contact. Exposed surfaces of the pump shaft should be protected with a rust preventative. All dismantled parts should be wrapped and tagged according to pump serial number and a record kept of their location.



Pumps covered with plastic should not be stored in a cool environment because resulting condensation can cause rusting.

2.5 Recycling and end of product life

At the end of the service life of the product or its parts, the relevant materials and parts should be recycled or disposed of using an environmentally acceptable method and in accordance with local regulations. If the product contains substances that are harmful to the environment, these should be removed and disposed of in accordance with current local regulations. This also includes the liquids and/or gases that may be used in the "seal system" or other utilities.



Make sure that hazardous substances are disposed of safely and that the correct personal protective equipment is used. The safety specifications must be in accordance with the current local regulations at all times.

3 PUMP DESCRIPTION

3.1 Configurations

Flowserve "R Slurry" pumps are single stage, end suction centrifugal pumps specifically designed for handling abrasive slurries typical of mining and mineral process. The casing is radially split with the gland side casing pedestal mounted. The discharge is tangential. The casings are fitted with removable rubber liners. The closed impeller with rear pump-out vanes is capable of passing solids of various sizes. Sealing is provided at the impeller to shaft fit to prevent corrosion and thereby facilitate impeller removal. The rigid three point thrust bearing housing support permits precision bearing alignment. Since the casing is pedestal mounted, back pull-out is not a normal feature.

The pump is sealed using non-asbestos packing in the stuffing box. An optional hydrodynamic seal, commonly referred to as an expeller is available and various mechanical seal designs as specified by the customer may be installed at the factory or retrofitted in the field.


All pumps are carefully inspected and prepared for shipment. All exterior machined surfaces are coated with a rust preventative compound and openings are provided with covers or plugs. Shaft packing, when required, is shipped with the pump and should not be installed until the pump is ready to run. Mechanical seals, when provided, are factory installed and adjusted prior to shipment. The axial impeller running clearance is pre-set at the factory but should be checked prior to final alignment in case of tampering.

These User Instructions also cover the RX and RS configurations, check the nameplate against the nomenclature.

3.2 Name nomenclature

The pump size will be engraved on the nameplate. The following example explains how the pump name identifies the construction features and options.

8R-193



R is the basic pump type
RX is designated for expeller

3.3 Design of major parts

3.3.1 Pump casing

The pump casing is a semi-concentric volute type casing and tangential discharge nozzle and is radially split. The casings are cast iron and are pedestal mounted therefore the discharge can be rotated to meet a number of optional orientations (**Self venting only with the discharge in the top vertical or top horizontal orientation**). It is fitted with replaceable rubber liners. The casing joints are self-sealed by the rubber liners however optional urethane lined casing may require gaskets at some flange connections. The casing flanges are also drilled and tapped.

3.3.2 Impeller

The impeller is a closed design as standard but may be changed to open designs for mud, froth and viscous applications. The impeller is thread mounted to the shaft. All impellers are supplied with pump out vanes to minimise wear and reduce pressure at the stuffing box. The vanes are curved to optimize efficiency however, the “S” configuration utilizes straight radial vanes to reduce blockage. The impeller of the RS pump has larger front clearances to reduce shear and improve froth handling capabilities.

3.3.3 Shaft

The large diameter stiff shaft, mounted on bearings, has a keyed drive end. The shaft extension at the coupling is extended to cover multi-v-belt drives.

3.3.4 Pump bearings and lubrication

Ball bearings are fitted as standard and may be either oil or grease lubricated.

Oil lubrication is only available where the pump shaft is horizontal. The bearings on frame 6 pumps (18R416) cannot be grease lubricated.

3.3.5 Bearing housing

For oil lubricated bearings, a bulls eye level gauge is supplied. Constant level oilers can also be fitted. Two grease nipples enable grease lubricated bearings to be replenished between major service intervals.

3.3.6 Stuffing box housing

The stuffing box is a loose design and has a spigot (rabbet) fit with the pump casing. The design enables a number of sealing options to be fitted, as well a wide range of materials options.

3.3.7 Shaft seal

The mechanical seal(s), attached to the pump shaft, seals the pumped liquid from the environment. Gland packing may be fitted as an option. The “X” model is fitted with an optional dynamic or expeller seal for certain applications.

3.3.8 Driver

The driver is normally an electric motor. Due to the hardness of the impeller the norm is to use multi-v-belts. Different drive configurations may be fitted such as internal combustion engines, turbines, hydraulic motors etc driving via couplings, belts, gearboxes, drive shafts etc.

3.3.9 Accessories

Accessories may be fitted when specified by the customer.

3.4 Performance and operating limits

This product has been selected to meet the specifications of your purchase order see section 1.5. The following data is included as additional information to help with your installation. It is typical, and factors such as temperature, materials, and seal type may influence this data. If required, a definitive statement for your particular application can be obtained from Flowserve.

3.4.1 Operating limits

3.4.1.1 Temperature

Liner Materials	Maximum Operating Temperature
Natural Rubber-soft	65°C (150°F)
Natural Rubber-Hard	80°C (176°F)
Nitrile	93°C (200°F)
Neoprene	100°C (212°F)

3.4.1.2 Pressure

The maximum working pressure will be 110 PSIG for all sizes except for the 18R416 which will be 100 PSIG. Vacuum service should be avoided due to potential of rubber liner collapse.

3.4.2 Speed torque curves


To bring a centrifugal pump up to rated speed, the driver must be capable of providing more torque at each speed than required by the pump. The margin between the available and required torque affects the time it takes the unit to reach full speed. If the torque required by the pump exceeds the torque capability of the drive at any run-up speed, the unit will not accelerate to full speed. Normally, this is not a problem with standard induction or synchronous motors provided the proper voltage is supplied at the motor.

For pumps started at shut valve conditions, 100 percent full speed torque can be calculated by using the formula:

$$\text{Torque (Nm)} = 9545 \frac{\text{Shutoff Power (kW)}}{\text{r/min}}$$

$$\text{Torque (ft.lb)} = 5250 \frac{\text{Shutoff Power (hp)}}{\text{r/min}}$$

Torque required by the pump at any other speed during start-up can be determined from the curve below. Note that the driver manufacturer usually bases 100 percent torque on the design power of the driver and consequently the speed-torque curves should be plotted in torque units (e.g. Nm) instead of percentage torque to avoid confusion.



3.4.3 MAXIMUM WORKING PRESSURES -bar (psi).

Above ambient temperature these maximum pressures shall be derated.



Do not conduct a hydro on the complete pump set without the specific approval of Flowserve. While the duty requirement will have been covered, auxiliary items, flange drillings and suction pressure limits may impose a reduced static and dynamic pressure rating compared to that of the pump casting rating itself.

Note: all flanges are dimensionally compatible with ANSI 125 (Cast Iron or Ductile Iron-flat faced) or ANSI 150 (Stainless-raised face) unless otherwise stated. All flange facings on the casings are 250 rms – circular finish (Stock Finish)

3.5 Materials of Construction

BASIC CONSTRUCTION	Natural Rubber Lined	Neoprene Lined	Nitrile Lined	
Casing – Suction and Gland Side	ASTM A48 CL 35 (Cast iron)			
Stuffing Box	ASTM A48 CL35 (Cast iron) (2)			
Suction Side liner, Gland side Liner	Natural Rubber	Neoprene	Nitrile	
Impeller	Natural Rubber	Neoprene	Nitrile	
Protector Plate	HARD STEEL –360 BHN (2) (3)			
Impeller Spacer	HARD STEEL –360 BHN (2) (3)			
Shaft Sleeve	ASTM A743 CG3M (1)			
Shaft	AISI 1045			
Gland Halves	ASTM A743 CF8M (316)			
Pipe Plugs (Stuffing Box)	C.I. (2)			
Gland Studs And Nuts	AISI 316			
Liner Studs & Nuts	AISI 1018/1020 Steel			
PACKING	SYNTHETIC FIBRE			
SEAL CAGE HALVES	ASTM A743 CG8M			
GASKETS-CASING	SYNTHETIC FIBRE			
GASKETS-SLEEVE	TEFLON			
O-RINGS	BUNA-N (120° C MAX.)			
MISC. FASTNERS, PARTS	STEEL			

- (1) Nickel-Chrome-Boron Coated, except for units with mechanical seals.
- (2) For acid kit construction 316 SS (standard) or Alloy C (optional) materials will be supplied. Refer to Flowserve for additional material options.
- (3) For severe abrasive applications Stellite 4 is available.



3.6 Tables of Engineering Data

3.6.1 (FRAMES 0, 1 & 2 - LIQUID END)

ENGINEERING DATA	1 1/4R090	2 1/2R090	3R090	2 1/2R091	3R091	3R111	4R122	5R142
PUMP DESIGN TYPE	STD	STD	STD	STD	STD	STD	STD	STD
SUCTION SIZE mm (in.)	38 (1.5)	64 (2.5)	76 (3)	64 (2.5)	76 (3)	102 (4)	127 (5)	152 (6)
DISCHARGE SIZE mm (in.)	32 (1.25)	64 (2.5)	76 (3)	64 (2.5)	76 (3)	76 (3)	102 (4)	127 (5)
MAX. SPHERE SIZE mm (in.)	10(0.38)	15 (0.6)	23 (0.9)	15 (0.6)	23 (0.9)	31 (1.2)	43 (1.7)	48 (1.9)
VVK ² (wet) kg · m ² (lb · ft ²)	0.12 (2.8)	0.12 (2.8)	0.11 (2.6)	0.12 (2.8)	0.11 (2.6)	0.21 (4.9)	0.44 (11)	0.82 (19)
PUMP WEIGHT kg (lbs)	195 (430)	218 (480)	241 (530)	241 (530)	264 (580)	286 (630)	391 (860)	486 (1 070)
IMPELLER CLEARANCE mm (in.)	0.38 (0.015)		0.38 (0.015)		0.38 (0.015)		0.76 (0.030)	
O.D. SLEEVE mm (in.)	50.8 (2.0)		50.8 (2.0)		50.8 (2.0)		76.2 (3.0)	
La STUFFING BOX mm (in.)	69.85 (2.75)		69.85 (2.75)		69.85 (2.75)		101.6 (4.0)	
DEPTH OF BOX mm (in.)	71.4 (2.81)		71.4 (2.81)		71.4 (2.81)		93.5 (3.68)	
PACKING SIZE mm (in.)	9.5 (0.375)		9.5 (0.375)		9.5 (0.375)		12.7 (0.5)	
RECOMMENDED PACKING	L5		L5		L5		L5	
ALTERNATIVE PACKING	2L3		2L3		2L3		2L3	

3.6.2 (FRAMES 0, 1 & 2 - FRAME DETAILS)

ENGINEERING DATA		1¼ R090	2½ R090	3 R090	2½ R091	3 R091	3 R111	4 R122	5 R142
		SHAFT AND BEARING DATA							
DIA. AT IMPELLER	mm	22.4			28.58		34.93		
	(in.)	(0.88)			(1.125)		(1.375)		
DIA. UNDER SLEEVE	mm	25.4			41.27		66.68		
	(in.)	(1.00)			(1.625)		(2.625)		
DIA. BETWEEN BEARINGS	mm	47.8			63.5		91.9		
	(in.)	(1.88)			(2.50)		(3.62)		
DIA. AT COUPLING	mm	25.4			41.27		63.5		
	(in.)	(1.00)			(1.625)		(2.500)		
LINE BEARING		6307			6311		6316		
THRUST BEARING		3307			7309 BUA		7314 BUA		
BEARING SPAN	mm	168			193.8		279.4		
	(in.)	(6.61)			(7.63)		(11.00)		
NOM. IMPELLER OVERHANG	mm	180			207.8		204.7		
	(in.)	(7.09)			(8.18)		(8.06)		
L10 BEARING LIFE		MINIMUM 3 YEARS							
BEARING SEALS									
THRUST BEARING LIP SEAL		C/R 12458			C/R 16246		C/R 24982		
					NAT. 473010		NAT. 417449		
LINE BEARING LIP SEAL		C/R 9998			C / R 19832		NAT. 417350		
					NAT. 472492				
THRUST BEARING O-RING		#240			#250		#263		
LINE BEARING O-RING		N/A			#246		#259		

3.6.3 (FRAME 3, 4 & 6 - LIQUID END)

ENGINEERING DATA		6 R163	8 R193	10 R234	12 R264	18 R416
SUCTION SIZE	mm (in.)	203 (8)	254 (10)	305 (12)	356 (14)	508 (20)
DISCHARGE SIZE	mm (in.)	152 (6)	203 (8)	254 (10)	305 (12)	457 (18)
MAX.SPHERE SIZE	mm (in.)	53 (2.10)	71 (2.80)	91 (3.60)	81 (3.20)	50.8 (2.00)
WK ² (wet)	kg x m ² lb-ft ²	1.81 (43)	3.62 (86)	8.83 (209)	12.6 (298)	86.79 (2056)
PUMP WT.	Kg (Lbs)	832 (1830)	1009 (2220)	1582 (3480)	2100 (4620)	7273 (16000)
IMPELLER CLEARANCE	mm (in.)	1.14 (0.045)		1.5 (0.06)		1.8 (0.07)
O.D.SLEEVE	mm (in.)	95.25 (3.75)		120.7 (4.75)		184.1 (7.250)
I.D.STUFFING BOX	mm (in.)	127 (5.00)		152.4 (6.00)		222.3 (8.75)
DEPTH	mm (in.)	116.3 (4.58)		116.3 (4.58)		165 (6.5)
PACKING SIZE	mm (in.)	15.9 x 15.9 (0.63 x 0.63)		15.9 x 15.9 (0.63 x 0.63)		19.1 x 19.1 (.75 x .75)
RINGS OF PACKING		5		5		6
Recommended PACKING		L5		L5		L6
Alternative Packing		2L3		2L3		2L4

3.6.4 (FRAMES 3, 4 & 6- FRAME DETAILS)

ENGINEERING DATA		6 R163	8R193	10 R234	12R264	18R416
SHAFT AND BEARING DATA						
DIA. AT IMPELLER	mm	50.8	98.6	139.7		
	(in.)	(2.00)	(3.88)	(5.50)		
DIA. UNDER SLEEVE	mm	82.55	108	160		
	(in.)	(3.25)	(4.25)	(6.30)		
DIA. BETWEEN BEARINGS	mm	91.9	146.1	184.2		
	(in.)	(3.62)	(5.75)	(7.25)		
DIA. AT COUPLING	mm	85.72	104.78	146.05		
	(in.)	(3.375)	(4.125)	(5.75)		
LINE BEARING		21320	22226C	24034HL		
THRUST BEARING		7318 BUA	QJ322/NU322	29334E 23134HL		
BEARING SPAN	mm	279.4	513	874		
	(in.)	(11.00)	(20.20)	(34.41)		
NOM. IMPELLER OVERHANG	mm	245.4	355	699		
	(in.)	(9.66)	(13.96)	(27.50)		
L10 BEARING LIFE		MINIMUM 3 YEARS				
BEARING SEALS						
THRUST BEARING LIP SEAL		NAT. 417191	NAT. 417511	C/R 57510 GARL. 53x3275		
		C/R 37389 NAT. 417379	C/R 42419 NAT. 416556	C/R 63700 GARL. 53x3409		
THRUST BEARING O-RING		#269	#276	N/A		
LINE BEARING O-RING		#267	#269	N/A		

4 INSTALLATION



Equipment operated in hazardous locations must comply with the relevant explosion protection regulations. See section 1.6.4, *Products used in potentially explosive atmospheres*.



Pump discharge is to stay within the top vertical or top horizontal discharge position to prevent the build-up of trapped gas. See section, 8.6 *General Arrangement of Pump Discharge Orientation*.

4.1 Location

The pump should be located to allow room for access, ventilation, maintenance and inspection with ample headroom for lifting and should be as close as practicable to the supply of liquid to be pumped. Allow sufficient room to facilitate the back pull-out feature on V-belt driven units.

Refer to the general arrangement drawing for the pump set.

4.2 Part assemblies

Motors may be supplied loose on R Slurry pumps, typically on frame sizes 400 and above. It is the responsibility of the installer to ensure that the motor is assembled to the pump and lined up as detailed in section 4.5.2.

4.3 Foundation



The foundation may consist of any material that will afford permanent, rigid support to the full area of the pump or driver supporting member. It should be of sufficient size and mass to absorb expected strains and shocks that may be encountered in service. Concrete foundations built on solid ground are desirable.

The purpose of foundation bolts is to anchor the pump unit securely to the foundation such that the foundation and pump assembly become a single structural unit. High strength steel foundation bolts (SAE Gr. 5 or equal) of the specified diameter should be located according to the elevation drawing provided. Each bolt should be surrounded by a pipe sleeve that is two or three times the diameter of the bolt. The sleeves should be securely anchored and designed to allow the bolts to be moved to conform with the holes in the baseplate. The bolts should be sufficiently long to allow for wedges or shims or levelling nuts under the baseplate, and a washer, heavy hex nut and hex jam nut for retention. Since baseplate levelling is performed after the foundation has cured, it is best to use extra long bolts that can be shortened after the installation is complete.

4.4 Baseplate installation

Position the baseplate and pump next to the foundation and clean the foundation surface thoroughly. Remove the rag packing from the pipe sleeves and place wedges or shims as close to the foundation bolts as possible. These may be omitted if a jacking nut on the foundation anchor bolts is preferred for levelling. Initial levelling should be within 0.75 mm (.030 inches).


Remove the flange covers and check inside the pump nozzles for cleanliness. Kerosene is recommended as the best solvent for removing factory applied rust preventative from metal surfaces. Ensure that all traces of rust preventative are removed from the discharge and suction flange faces, the exposed shafting and all coupling surfaces. Flush the pump internals of any rust preventative applied for long-term storage.

Lift the baseplate assembly, remove the shipping skids and clean the underside of the baseplate. Position the baseplate over the foundation and lower the unit over the foundation bolts and onto the wedges, shims or jacking nuts.

With the aid of a machinist's level, adjust the wedges, shims or jacking nuts to level the pump and driver mounting pads in each direction. Check to ensure that the suction and discharge flanges are plumb, level, and at the correct elevation. It is normal practice to set the mounting pads slightly low in order to permit lowering of units which may be required to suit future piping or minor changes. Place washers over the foundation bolts and install nuts. Tighten finger tight only.

Check the impeller axial clearance and that the rotor turns freely by hand.

Note: Grout is not poured until an initial alignment of the pump and driver has been performed.



4.5 Initial alignment

4.5.1 Thermal expansion



The pump and motor will normally have to be aligned at ambient temperature and should be corrected to allow for thermal expansion at operating temperature. In pump installations involving high liquid temperatures, the unit should be run at the actual operating temperature, shut down and the alignment checked immediately.

4.5.2 Direct Driven Limits



Ensure pump and driver are isolated electrically and the half couplings are disconnected.



The alignment **MUST** be checked. Although the pump will have been aligned at the factory it is most likely that this alignment will have been disturbed during transportation or handling. If necessary, align the motor to the pump, not the pump to the motor.

4.5.3 Alignment Methods:

The importance of accurate alignment of pump and driver shafts cannot be overemphasized.


IMPROPER ALIGNMENT IS THE PRIMARY CAUSE OF VIBRATION PROBLEMS AND REDUCED BEARING LIFE.

A flexible coupling is used to compensate for slight changes in alignment that occur during normal operation and is not used to correct for installation errors. Install the pump and driver half couplings in accordance with the coupling manufacturer's instructions. Note that the coupling hub faces are not always mounted flush with the ends of the shafts. Place the driver on the baseplate such that the correct spacing is obtained between the two half couplings. In the case of electric motors, such as those with sleeve bearings, it may be necessary to run the motor to establish the rotor magnetic center. Consult the manufacturer's instruction manual for details.


The purpose of the alignment procedure is to ensure that the pump and driver shafts are in parallel and angular alignment under the normal operating conditions of load and temperature.

When the pump coupling and driver are assembled at the factory, the units are aligned prior to shipment. However, baseplates can be sprung or distorted during shipment or installation and the alignment

must be checked before the unit is put in service.



PARALLEL MISALIGNMENT— Shafts with axis parallel but not concentric




ANGULAR MISSALIGNMENT — Shafts with axis concentric but not parallel.

The coupling spacer must be removed to make this check.

For pumps and drivers that operate at different temperatures compensation must be made at the initial alignment stage (when the units are at the same temperature) to allow for thermal expansion during operation. Consult the instruction manual supplied with the driver for the manufacturer's recommendations.

Shaft alignment is greatly simplified by the use of a dial indicator with extension rods and a magnetic base. Before taking readings, ensure that the pump and driver mounting bolts are secure, and that the thrust bearing housing is properly aligned in the bearing frame or cartridge.

4.5.3.1 Parallel Alignment:



CHECKING PARALLEL MISALIGNMENT

Mount the magnetic base on the pump half coupling hub, either the face or O.D. as shown in the sketch.


Place the dial indicator button on the outside diameter of the driver half coupling hub.

Note: The length of extension rods should be kept at a minimum to reduce deflection.

Rotate the pump shaft and record the dial reading at the top, bottom and each side. Correct the parallel alignment by adding or removing shims under the driver and/or moving the driver horizontally. Repeat this procedure until the maximum total indicator reading (T.I.R.) is within 0.076 mm (0.003 inch.)

4.5.3.2 Angular Alignment:

Mount the magnetic base on the pump half coupling hub, either the face or O.D. as shown in the sketch. Move the dial indicator button to indicate on the face of the driver half coupling hub as close to the outside diameter as possible. When convenient the indicator can be placed on the inside face to keep spans short. Turn both shafts 360° and record the dial readings at 90° intervals. Adjust the shims under the motor as required and repeat the procedure until the angular alignment is within 0.0005 mm (T.I.R.) per mm (0.0005 inch per inch) of maximum hub diameter.



CHECKING ANGULAR MISALIGNMENT

Repeat the checks on parallel and angular alignment, ensuring the mounting bolts are secure, until the unit is properly aligned. Note that correction in one direction may affect the alignment in another direction. Re-check the gap between the coupling hubs.

If any difficulty is encountered in achieving the recommended alignment tolerances, the runout of the pump and driver shafts and each coupling hub diameter and face should be checked. Occasionally, due to practical and unavoidable manufacturing tolerance build-up associated with the pump, coupling and driver, it may be necessary to match up the two coupling hubs in the most advantageous relative angular position in order to achieve an acceptable alignment.

Do not install the coupling spacer or sleeve until grouting is complete and cured and the alignment is re-checked.


When the electric motor has sleeve bearings it is necessary to ensure that the motor is aligned to run on its magnetic centerline. A button (screwed into one of the shaft ends) is normally fitted between the motor and pump shaft ends to fix the axial position.

CAUTION If the motor does not run in its magnetic center the resultant additional axial force may overload the pump thrust bearing.

CAUTION Complete piping as below and see sections 4.7, *Final shaft alignment check* up to and including section 5, *Commissioning, start-up, operation and shutdown* before connecting driver and checking actual rotation.

4.5.4 V-Belt Drive Units:

Check that both sheaves are free of grease, rust, nicks or burrs. Install the correct size sheave on the pump shaft and locate the sheave axially to minimize overhang. Re-check the impeller axial clearance and ensure that the pump is properly secured to the baseplate. Install the driver on the adjustable base provided and install the driver sheave in line with the pump sheave. Ensure that the sheaves are tight on the shafts. With a dial indicator, check the runout on the periphery and face of each sheave to ensure that each is running true. Tighten the adjustable base and check that the driver rotation is in the correct direction and that vibration levels are not unacceptable.



WRONG WRONG RIGHT

CHECKING V-BELT SHEAVE ALIGNMENT

Checking V-Belt Sheave Alignment

CAUTION Before starting the driver, refer to the manufacturer's instruction manual. The correct rotation

of the pump shaft is marked on the pump casing or frame.

Check that all belts making up one drive set have matched code numbers. Loosen the adjustable base and install the belts in their proper grooves. Adjust the center distance between the sheaves to obtain proper belt tension. Check the alignment of the pump and driver sheaves with a taught string or straight edge. For proper alignment and the sheave faces must be parallel to each other and in line. Adjustments are made by slackening the belts and moving the sheaves. Retighten the drive or driver sheave then recheck. The procedure may need to be repeated to get alignment as close as possible.

When the sheaves are aligned, check that the shafts rotate freely by hand and install safety guard.



Belt drives must not be used in ATEX Potentially explosive environments; refer to Flowserve.

4.6 Grouting

The purpose of grouting is to provide rigid support to the pump and driver by increasing the structural rigidity of the baseplate and making it an integral mass with the foundation.

Clean the roughed foundation surface and build a wooden form around the baseplate. For initial grouting forms should be placed to isolate shims and levelling nuts. The foundation surface should be thoroughly saturated with water before grouting. A typical mixture for grouting-in a pump base is composed of one part pure Portland cement and two parts of clean building sand with sufficient water to provide the proper consistency. The grout should flow freely but not be so wet as to cause the sand and cement to separate.

Thoroughly puddle the grout while pouring to eliminate air pockets and low spots. Pour sufficient grouting to ensure that the bottom surface of the baseplate is completely submerged. Do not fill isolated areas around the shims or levelling nuts. Once the grout has set sufficiently, remove the wooden forms and finish off the sides and top as desired. At the same time, roughen the grout surface inside the baseplate. Cover with wet burlap and allow the grout to cure for at least 40 hours.

After grouting has cured, shims and levelling nuts should be removed or backed off. Tighten down baseplate to the new grout to put bolts in tension and ensure rigidity of structure. Install jam nuts and cut the bolts to the desired length. Finish grouting isolated areas. Fill the baseplate including pump and driver

support pedestals with concrete. Trowel and slope the surface to give suitable drainage.

4.7 Piping



Protective covers are fitted to the pipe connections to prevent foreign bodies entering during transportation and installation. Ensure that these covers are removed from the pump before connecting any pipes.

4.7.1 Suction and discharge pipework

In order to minimize friction losses and hydraulic noise in the pipework it is good practice to choose pipework that is one or two sizes larger than the pump suction and discharge. Typically, main pipework velocities should not exceed 2 m/s (6 ft/sec) suction and 3 m/s (9 ft/sec) on the discharge.

Take into account the available NPSH which must be higher than the required NPSH of the pump.



Never use the pump as a support for piping.

Maximum forces and moments allowed on the pump flanges vary with the pump size and type. To minimize these forces and moments that may, if excessive, cause misalignment, hot bearings, worn couplings, vibration and the possible failure of the pump casing, the following points should be strictly followed:

- Prevent excessive external pipe load
- Never draw piping into place by applying force to pump flange connections
- Do not mount expansion joints so that their force, due to internal pressure, acts on the pump flange

The table in 4.7.2 summarizes the maximum forces and moments allowed on R pump casings. Refer to Flowserve for other configurations.



Ensure piping and fittings are flushed before use.




Ensure piping for hazardous liquids is arranged to allow pump flushing before removal of the pump.

4.7.1.1 Flange Facing

R Pumps are designed so that the connecting pipes at the suction and discharge can be attached without gaskets. To ensure correct sealing and rubber pinch, standard flat face weld neck flanges must be used. Any arrangements other than that shown will affect pump internal clearances, cause leakage at the

flanges or result in serious damage to the rubber parts.


CAUTION Do not use raised face flanges



4.7.1.2 Flange Size

a) It is necessary that the I.D. of the pipe flange match the I.D. of the properly seated liner nozzle. The suction flange face must be to the nominal flange size, ie for a 12" flange the flange ID should be 12". This can be a particular problem where thinner walled piping is used which has larger inside diameters. Weld neck flanges that match the thinner pipes will reduce clamping area at pump flange and could lead to a collapse of the suction nozzle in the pump.

CAUTION Flange I.D. to be nominal size.




4.7.1.3 Flange Design

Depicted in the sketch above is the suction of the pump but information applies to the discharge as well. The rubber seal lip, which protrudes beyond the flange face of the metal casing must be completely


compressed at assembly to ensure a seal and retain the liner nozzle. At assembly and prior to installing piping ensure that the lip is properly seated in the recess of the casing.

4.7.1.4 Spool Installation

The sketch below illustrates that a short spool is recommended to connect to the flange. The spool should be moved perpendicular to the flange so that the rubber sealing lip is not dislodged. If the spool is slid into the flange from the side the sealing lip may be pushed out of the recess and/or the rubber nozzle distorted making it impossible to obtain a seal.



spool piece when bolted to the casing will fully compress the rubber sealing lip into the recess, this will provide a positive metal to metal fit. When the spool is used with a properly designed flange the compression of the rubber is controlled. The flange bolts are designed for a maximum engagement of 1.5X the bolt size. Use of longer bolts in the suction could distort and damage the liner. Bolts that are too long in the discharge may bottom out in the blind flange. Before the bolts are tightened, ensure that the




I.D. of the spool is even and uniform with the rubber bore. Figure 8C shows the alignment and illustrates the suction flange bolting.

Once the spool is installed additional suction piping may be installed. These flange joints will require

gaskets. Figure 8D illustrates the assembly of other piping, flange facings at other joints than the pump may be raised of flat.

4.7.2 Maximum forces and moments allowed on R Slurry pump flanges



Maximum forces (F) in N (lbf) and moments (M) in Nm (lbf•ft)

Pump Size	Suction						Discharge					
	Mx	My	Mz	Fx	Fy	Fz	Mx	My	Mz	Fx	Fy	Fz
2.5R091	710 (520)	350 (260)	540 (400)	1110 (250)	890 (200)	760 (170)	710 (520)	350 (260)	540 (400)	890 (200)	760 (170)	1110 (250)
3R091	950 (700)	470 (350)	720 (530)	1070 (240)	890 (200)	1330 (300)	950 (700)	470 (350)	720 (530)	1070 (240)	890 (200)	1330 (300)
3R111	1330 (980)	680 (500)	1000 (740)	1780 (400)	1420 (320)	1160 (260)	950 (700)	470 (350)	720 (530)	1070 (240)	890 (200)	1330 (300)
4R122	1830 (1340)	940 (690)	1450 (1070)	2450 (550)	1960 (440)	1600 (360)	1330 (980)	680 (500)	1000 (740)	1420 (320)	1160 (260)	1780 (400)
5R142	2300 (1700)	1180 (870)	1760 (1300)	3110 (700)	2490 (560)	2050 (460)	1830 (1340)	940 (690)	1450 (1070)	1960 (440)	1600 (360)	2450 (550)
6R163	3530 (2600)	1760 (1300)	2580 (1900)	4890 (1100)	3780 (850)	3110 (700)	2300 (1700)	1180 (870)	1780 (1300)	2490 (560)	2050 (460)	3110 (700)
8R193	5020 (3700)	2440 (1800)	3800 (2800)	6670 (1500)	5340 (1200)	4450 (1000)	3530 (2600)	1760 (1300)	2580 (1900)	3780 (850)	3110 (700)	4890 (1100)
10R234	6100 (4500)	2980 (2200)	4610 (3400)	8000 (1800)	6670 (1500)	5340 (1200)	5020 (3700)	2440 (1800)	3800 (2800)	5340 (1200)	4450 (1000)	6670 (1500)
12R264	6370 (4700)	3120 (2300)	4750 (3500)	8900 (2000)	7120 (1600)	5780 (1300)	6100 (4500)	2980 (2200)	4610 (3400)	6670 (1500)	5340 (1200)	8000 (1800)
18R416	9080 (6700)	4750 (3500)	6780 (5000)	12900 (2900)	10720 (2410)	8450 (1900)	8200 (6050)	4200 (3100)	6100 (4500)	9610 (2160)	7560 (1700)	11570 (2600)

Notes:

- 1) F = External force (tension or compression) M = External moment, clockwise or counter-clockwise
- 2) Forces and moments may be applied simultaneously in any direction
- 3) Values apply to all materials
- 4) Higher loads may be applicable, if direction and magnitude of individual loads are known, but these need written approval from Flowserve
- 5) Pumps must be on rigid foundations and baseplates must be fully grouted
- 6) Pump/baseplate should not used as pipe anchor. Expansion joints must be properly tied
- 7) The pump mounting bolt torques specified must be used to prevent relative movement between the pump casing and baseplate. (See section 6.6, *Fastener torques*.) The bolt material must have a minimum yield strength of 600 N/mm² (87 000 lb/in.²)

4.7.3 Suction piping

- a) The inlet pipe should be one or two sizes larger than the pump inlet bore and pipe bends should be as large a radius as possible.
- b) Pipework reducers should have a maximum total angle of divergence of 15 degrees.
- c) On suction lift the piping should be inclined up towards the pump inlet with eccentric reducers incorporated to prevent air locks.
- d) On positive suction, the inlet piping must have a constant fall towards the pump.
- e) Flow should enter the pump suction with uniform flow, to minimize noise and wear. This is particularly important on large or high-speed pumps which should have a minimum of four diameters of straight pipe on the pump suction between the elbow and inlet flange. See section 10.3, *Reference 1* for more detail.
- f) Inlet strainers, when used, should have a net 'free area' of at least three times the inlet pipe area.
- g) Do not install elbows at an angle other than perpendicular to the shaft axis. Elbows parallel to the shaft axis will cause uneven flow.
- h) Except in unusual circumstances strainers are not recommended in inlet piping. If considerable foreign matter is expected a screen installed at the entrance to the wet well is preferable.
- i) Fitting an isolation valve will allow easier maintenance.
- j) Never throttle pump on suction side and never place a valve directly on the pump inlet nozzle.

4.7.4 Discharge piping

A non-return valve should be located in the discharge pipework to protect the pump from excessive back pressure and hence reverse rotation when the unit is stopped.

Pipework reducers should have a maximum total angle of divergence of 15 degrees. Fitting an isolation valve will allow easier maintenance.

4.7.5 Auxiliary piping

4.7.5.1 Drains

Pipe pump casing drains and gland leakage to a convenient disposal point.

4.7.5.2 Pumps fitted with gland packing

When suction pressure is below ambient pressure it is necessary to feed the gland packing with liquid to provide lubrication and prevent the ingress of air. This is normally achieved with a supply from the pump discharge volute to the stuffing box. A control valve is fitted in the line to enable the pressure to the gland to be controlled.

If the pumped liquid is dirty and cannot be used for sealing, a separate clean compatible liquid supply to the gland at 1 bar (15 psi) above suction pressure is recommended.

4.7.5.3 Pumps fitted with mechanical seals

Single seals requiring re-circulation will normally be provided with the auxiliary piping from pump casing already fitted.

If the seal requires an auxiliary quench then a connection must be made to a suitable source of liquid flow, low pressure steam or static pressure from a header tank. Recommended pressure is 0.35 bar (5 psi) or less. Check *General arrangement drawing*.

Special seals may require different auxiliary piping to that described above. Consult separate User Instructions and/or Flowserve if unsure of correct method or arrangement.

For pumping hot liquids, to avoid seal damage, it is recommended that any external flush/cooling supply be continued after stopping the pump.

4.7.6 Final checks


Check the tightness of all bolts in the suction and discharge pipework. Check also the tightness of all foundation bolts.


4.8 Final shaft alignment check


After connecting piping to the pump, rotate the shaft several times by hand to ensure there is no binding and all parts are free.

Recheck the coupling alignment, as previously described, to ensure no pipe strain. If pipe strain exists, correct piping.

4.9 Electrical connections

 **DANGER** Electrical connections must be made by a qualified electrician in accordance with relevant local, national and international regulations.

 It is important to be aware of the EUROPEAN DIRECTIVE on potentially explosive areas where compliance with IEC60079-14 is an additional requirement for making electrical connections.

 It is important to be aware of the EUROPEAN DIRECTIVE on electromagnetic compatibility when wiring up and installing equipment on site. Attention must be paid to ensure that the techniques used during wiring/installation do not increase

electromagnetic emissions or decrease the electromagnetic immunity of the equipment, wiring or any connected devices. If in any doubt, contact Flowserve for advice.



DANGER The motor must be wired up in accordance with the motor manufacturer's instructions (normally supplied within the terminal box) including any temperature, earth leakage, current and other protective devices as appropriate. The identification nameplate should be checked to ensure the power supply is appropriate.



A device to provide emergency stopping must be fitted.

If not supplied pre-wired to the pump unit, the controller/starter electrical details will also be supplied within the controller/starter.

For electrical details on pump sets with controllers see the separate wiring diagram



CAUTION See section 5.3, *Direction of rotation* before connecting the motor to the electrical supply.

4.10 Protection systems



The following protection systems are recommended particularly if the pump is installed in a potentially explosive area or is handling a hazardous liquid. If in doubt consult Flowserve.

If there is any possibility of the system allowing the pump to run against a closed valve or below minimum continuous safe flow a protection device should be installed to ensure the temperature of the liquid does not rise to an unsafe level.

If there are any circumstances in which the system can allow the pump to run dry, or start up empty, a power monitor should be fitted to stop the pump or prevent it from being started. This is particularly relevant if the pump is handling a flammable liquid.

If leakage of product from the pump or its associated sealing system can cause a hazard it is recommended that an appropriate leakage detection system is installed.

To prevent excessive surface temperatures at bearings it is recommended that temperature or vibration monitoring are carried out. See sections 5.7.4 and 5.7.5.

5 COMMISSIONING, START-UP, OPERATION AND SHUTDOWN



CAUTION *These operations must be carried out by fully qualified personnel.*

5.1 Pre-commissioning procedure

5.1.1 Lubrication

Determine the mode of lubrication of the pump set: grease, oil, product lubrication etc.



CAUTION For oil lubricated pumps, fill the bearing housing with correct grade of oil to the correct level; validate by sight glass or constant level oiler bottle.

When fitted with a constant level oiler, the bearing housing should be filled by unscrewing or hinging back the transparent bottle and filling the bottle with oil. Where an adjustable body Trico oiler is fitted this should be set to the proper height.

The oil filled bottle should then be refitted so as to return it to the upright position. Filling should be repeated until oil remains visible within the bottle.

Approximate oil volumes are shown in section 5.2.3, *Recommended Fill Capacities*.

Grease lubricated pumps and electric motors are supplied pre-greased.

Other drivers and gearboxes, if appropriate, should be lubricated in accordance with their manuals.



CAUTION In the case of product lubricated bearings, the source of product supply should be checked against the order. There may be requirements for an external clean supply, particular supply pressure or the commencement of lubrication supply before pump start-up.

5.2 Pump lubricants

5.2.1 Recommended oil lubricants

Centrifugal pump lubrication	Oil	Splash lubrication		Force feed lubrication
	Viscosity mm ² /s 40 °C	32	68	46
	Temp. maximum °C (°F)	65 (149)	80 (176)	-
	Designation according to DIN51502 ISO VG	HL/HLP 32	HL/HLP 68	HL/HLP 46
Oil companies and lubricants	BP	BP Energol HL32 BP Energol HLP32	BP Energol HL68 BP Energol HLP68	BP Energol HL46 BP Energol HLP46
	DEA	Anstron HL32 Anstron HLP32	Anstron HL68 Anstron HLP68	Anstron HL46 Anstron HLP46
	Elf	OLNA 32 HYDRELEF 32 TURBELF 32 ELFOLNA DS32	TURBELF SA68 ELFOLNA DS68	TURBELF SA46 ELFOLNA DS46
	Esso	TERESSO 32 NUTO H32	TERESSO 68 NUTO H68	TERESSO 46 NUTO H46
	Mobil	Mobil DTE oil light Mobil DTE13 MobilDTE24	Mobil DTE oil heavy medium Mobil DTE26	Mobil DTE oil medium Mobil DTE15M Mobil DTE25
	Q8	Q8 Verdi 32 Q8 Haydn 32	Q8 Verdi 68 Q8 Haydn 68	Q8 Verdi 46 Q8 Haydn 46
	Shell	Shell Tellus 32 Shell Tellus 37	Shell Tellus 01 C 68 Shell Tellus 01 68	Shell Tellus 01 C 46 Shell Tellus 01 46
	Texaco	Rando Oil HD 32 Rando Oil HD-AZ-32	Rando Oil 68 Rando Oil HD C-68	Rando Oil 46 Rando Oil HD B-46
	Wintershall (BASF Group)	Wiolan HN32 Wiolan HS32	Wiolan HN68 Wiolan HS68	Wiolan HN46 Wiolan HS46

5.2.2 Recommended grease lubricants

Grease	Grease nipples	
	NLGI 2 *	NLGI 3 **
Temp. range °C (°F)	-20 to +100 (-4 to +212)	-20 to +100 (-4 to +212)
Designation according to DIN	K2K-20	K2K 30
BP	Energrease LS2	Energrease LS3
DEA	Glissando 20	Glissando 30
Elf	Elfmulti 2	Elfmulti 3
Esso	Beacon 2	Beacon 3
Mobil	Mobilux 2	Mobilux 3
Q8	Rembrandt 2	Rembrandt 3
Shell	Alvania Fett G2 Alvania Fett R2	Alvania R3
Texaco	Multilak 20 Multilak EP2	Multilak 30 Multilak EP3
Wintershall (BASF Group)	Wiolub LFK 2	-
SKF	LGMT 2	LGMT 3
Silkolene	G55/T	G56/T

* NLGI 2 is an alternative grease and is not to be mixed with other grades

** Factory packed bearings for the temperature range with grease nipples

5.2.3 Recommended fill quantities

ASSEMBLY #	Approx. Qty Of Oil	
	LITRES	US GAL.
0	1.2	.3
1	1.2	.3
2	2.3	.6
3	3.5	.9
4	6.0	1.5
6	12	3

ASSEMBLY NO.	Grease Quantity			
	THRUST BRG.		LINE BRG.	
	cm ³	in. ³	cm ³	in. ³
1	20	1.2	40	2.4
2	60	3.6	80	4.9
3	140	8.5	100	6.1
4	180	11	120	7.3

5.2.4  **Lubrication schedule**

5.2.4.1 **Oil lubricated bearings**

Normal oil change intervals are 4 000 operating hours or at least every 6 months. For pumps on hot service or in severely damp or corrosive atmosphere, the oil will require changing more frequently. Lubricant and bearing temperature analysis can be useful in optimizing lubricant change intervals.

The lubricating oil should be a high quality, mineral oil having foam inhibitors. Synthetic oils may also be used if checks show that the rubber oil seals will not be adversely affected.

The bearing temperature may be allowed to rise to 50 °C (122 °F) above ambient, but should not exceed 82 °C (180 °F). A continuously rising temperature or an abrupt rise, indicate a fault.


5.2.4.2 **Grease lubricated bearings**

When grease nipples are fitted, one charge between grease changes is advisable for most operating conditions; 2 000 hours interval. See 6.2.3.1 for additional information.


Normal intervals between grease changes are 4 000 hours or at least every 6 months.

The characteristics of the installation and severity of service will determine the frequency of lubrication. Lubricant and bearing temperature analysis can be useful in optimising lubricant change intervals.


The bearing temperature may be allowed to rise to 55 °C (131 °F) above ambient but should not exceed 95 °C (204 °F). For most operating conditions a quality grease having a lithium soap base and NLGI consistency of No 2 or No 3 is recommended. The drop point should exceed 175 °C (350 °F).

 Never mix greases containing different bases, thickeners or additives.

5.3 **Direction of rotation**


 Ensure the pump is given the same rotation as the pump direction arrow cast on the pump casing. Rotation is clockwise when the pump is viewed from the driver.

To avoid dry running, the pump must either be filled with liquid or have the flexible coupling disconnected before driver is switched on.


 If maintenance work has been carried out to the site's electricity supply, the direction of


rotation should be re-checked as above in case the supply phasing has been altered.

5.4 **Guarding**

 Guarding is supplied fitted to the pump set. Fasteners for guards must remain captive in the guard to comply with the Machinery Directive 2006/42/EC. When releasing guards, the fasteners must be unscrewed in an appropriate way to ensure that the fasteners remain captive. Whenever guarding is removed or disturbed ensure that all the protective guards are securely refitted prior to start-up.

5.5 **Priming and auxiliary supplies**

 Ensure all electrical, hydraulic, pneumatic, sealant and lubrication systems (as applicable) are connected and operational.

 Ensure the inlet pipe and pump casing are completely full of liquid before starting continuous duty operation.

5.5.1 **Suction pressure above atmospheric pressure**

Horizontal pumps: Open suction line to pump, open vent connection in discharge pipe above pump to allow air to escape.

Vertical pumps: Open vent connection in discharge pipe at top plate and allow air to vent from pump casing and discharge piping. Let liquid run out until free from air bubbles.


5.5.2 **Suction lift with foot valve fitted**



Fill suction pipe and casing with liquid at a pressure of 1 to 2 bar from an external source. Vent as described in section 5.5.1.

5.5.3 **Suction lift without foot valve**

Pump casing vents on the suction volute or suction piping must be connected to an external vacuum pump priming system. If in doubt, please consult Flowserve.


5.6 **Starting the pump**

- a)  Ensure flushing and/or cooling/heating liquid supplies are turned ON before starting the pump.
- b) CLOSE the outlet valve.
- c) OPEN all inlet valves.
- d) Prime the pump.

- e)  Ensure all vent connections are closed before starting.
- f) Start motor and check outlet pressure.
- g) If the pressure is satisfactory, slowly OPEN outlet control valve.
- h)  Do not run the pump with the outlet valve closed for a period longer than 30 seconds.
- i) If NO pressure, or LOW pressure, STOP the pump. Refer to section 7, *Faults; causes and remedies*, for fault diagnosis.

5.7 Operating the pump


5.7.1 Venting the pump

 Vent the pump to enable all trapped air to escape taking due care with hot or hazardous liquids.

Under normal operating conditions, after the pump has been fully primed and vented, it should be unnecessary to re-vent the pump.


5.7.2 Pumps fitted with packed gland


If the pump has a packed gland there must be some leakage from the gland. Gland nuts should initially be finger-tight only. Leakage should take place soon after the stuffing box is pressurised.

 The gland must be adjusted evenly to give visible leakage and concentric alignment of the lantern ring [4134] to avoid excess temperature. If no leakage takes place the packing will begin to overheat. If overheating takes place the pump should be stopped and allowed to cool before being re-started. Loosen the gland. When the pump is re-started, check to ensure leakage is taking place at the packed gland.

If hot liquids are being pumped it may be necessary to slacken the gland nuts to achieve leakage.

The pump should be run for 30 minutes with steady leakage and the gland nuts tightened by 10 degrees at a time until leakage is reduced to an acceptable level, normally a minimum of 120 drops per minute is required. Bedding in of the packing may take another 30 minutes.


 Care must be taken when adjusting the gland on an operating pump. Safety gloves are essential. Loose clothing must not be worn to avoid being caught up by the pump shaft. Shaft guards must be replaced after the gland adjustment is complete.


 Never run gland packing dry, even for a short time.

5.7.3 Pumps fitted with mechanical seal


Mechanical seals require no adjustment. Any slight initial leakage will stop when the seal is run in.

Before pumping dirty liquids, it is advisable, if possible, to run in the pump mechanical seal using clean liquid to safeguard the seal face.

 External flush or quench should be started before the pump is run and allowed to flow for a period after the pump has stopped.

 Never run a mechanical seal dry, even for a short time.

5.7.4 Bearings


 If the pumps are working in a potentially explosive atmosphere temperature or vibration monitoring at the bearings is recommended

If bearing temperatures are to be monitored, it is essential that a benchmark temperature is recorded at the commissioning stage and after the bearing temperature has stabilized. Record the bearing temperature (t) and the ambient temperature (ta). Estimate the likely maximum ambient temperature (tb). Set the alarm at $(t+tb-t_a+5)^{\circ}\text{C}$ [$(t+tb-t_a+10)^{\circ}\text{F}$] and the trip at 100°C (212°F) for oil lubrication and 105°C (220°F) for grease lubrication.

It is important, particularly with grease lubrication, to keep a check on bearing temperatures. After start-up, the temperature rise should be gradual, reaching a maximum after approximately 1.5 to 2 hours. This temperature rise should then remain constant or marginally reduce with time. Refer to section 6.2.3.1 for further information.

5.7.5 Normal vibration levels, alarm and trip

For guidance, pumps generally fall under a classification for rigid support machines within the International rotating machinery standards and the recommended maximum levels below are based on those standards.

 Alarm and trip values for installed pumps should be based on the actual measurements (N) taken on the pump in the fully commissioned as new condition. Measuring vibration at regular intervals will then show any deterioration in pump or system operating conditions.

Vibration velocity – unfiltered mm/s (in./s) r.m.s.	R & RX
Normal N	≤ 7.6 (0.30)
Alarm N x 1.25	≤ 9.5 (0.37)
Shutdown trip N x 2.0	≤ 15.2 (0.60)



5.7.6 Stop/start frequency

Pump sets are normally suitable for the number of equally spaced stop/starts per hour shown in the table below. Check actual capability of the driver and control/starting system before commissioning.

Motor rating kW (hp)	Maximum stop/starts per hour
Up to 15 (20)	15
Between 15 (20) and 90 (120)	10
Above 90 (120)	6

Where duty and standby pumps are installed it is recommended that they run alternately every week.

5.8 Stopping and shutdown

- a)  Close the outlet valve, but ensure that the pump runs in this condition for no more than a few seconds.
- b) Stop the pump.
- c) Switch off flushing and/or cooling/heating liquid supplies at a time appropriate to the process.
- d)  For prolonged shut-downs and especially when ambient temperatures are likely to drop below freezing point, the pump and any cooling and flushing arrangements must be drained or otherwise protected.

5.9 Hydraulic, mechanical and electrical duty

This product has been supplied to meet the performance specifications of your purchase order, however it is understood that during the life of the product these may change. The following notes may help the user decide how to evaluate the implications of any change. If in doubt, contact your nearest Flowserve office.

5.9.1 Specific gravity (SG)

Pump capacity and total head in metres (feet) do not change with SG, however pressure displayed on a pressure gauge is directly proportional to SG. Power absorbed is also directly proportional to SG. It is therefore important to check that any change in SG will not overload the pump driver or over-pressurize the pump.

5.9.2 Viscosity

For a given flow rate, the total head reduces with increased viscosity and increases with reduced

viscosity. Also, for a given flow rate the power absorbed increases with increased viscosity and reduces with reduced viscosity. It is important that checks are made with your nearest Flowserve office if changes in viscosity are planned.

5.9.3 Pump speed

Changing pump speed effects flow, total head, power absorbed, NPSH_R, noise and vibration. Flow varies in direct proportion to pump speed; head varies as speed ratio squared; and power varies as speed ratio cubed. The new duty, however, will also be dependent on the system curve. If increasing the speed, it is important therefore to ensure the maximum pump working pressure is not exceeded, the driver is not overloaded, NPSH_A > NPSH_R, and that noise and vibration are within local requirements and regulations.

5.9.4 Net positive suction head (NPSH_A)

NPSH available (NPSH_A) is a measure of the head available in the pumped liquid, above its vapour pressure, at the pump suction branch.

NPSH required (NPSH_R) is a measure of the head required in the pumped liquid, above its vapour pressure, to prevent the pump from cavitating. It is important that NPSH_A > NPSH_R. The margin between NPSH_A > NPSH_R should be as large as possible.

If any change in NPSH_A is proposed, ensure these margins are not significantly eroded. Refer to the pump performance curve to determine exact requirements particularly if flow has changed. If in doubt, please consult your nearest Flowserve office for advice and details of the minimum allowable margin for your application.

5.9.5 Pumped flow

Flow must not fall outside the minimum and maximum continuous safe flow shown on the pump performance curve and/or data sheet.

5.9.6 Drive Efficiency

Various drive systems have efficiencies that may not be accounted for. Motor efficiencies are commonly known and accounted for in the motor selection. The use of VFD (variable frequency drives), MVD (multi-V belt drives) and gearboxes however should be considered. In VFD's the motor rating is based on full RPM and output power will be reduced proportionally with speed changes. Consult Flowserve Engineering for further information.

6 MAINTENANCE

6.1 General



It is the plant operator's responsibility to ensure that all maintenance, inspection and assembly work is carried out by authorized and qualified personnel who have adequately familiarized themselves with the subject matter by studying this manual in detail. (See also section 1.6.2.)

Any work on the machine must be performed when it is at a standstill. It is imperative that the procedure for shutting down the machine is followed, as described in section 5.8.

On completion of work all guards and safety devices must be re-installed and made operative again.

Before restarting the machine, the relevant instructions listed in section 5, *Commissioning, start up, operation and shut down* must be observed.

Oil and grease leaks may make the ground slippery. Machine maintenance must always begin and finish by cleaning the ground and the exterior of the machine.

If platforms, stairs and guard rails are required for maintenance, they must be placed for easy access to areas where maintenance and inspection are to be carried out. The positioning of these accessories must not limit access or hinder the lifting of the part to be serviced.

When air or compressed inert gas is used in the maintenance process, the operator and anyone in the vicinity must be careful and have the appropriate protection.

Do not spray air or compressed inert gas on skin.

Do not direct an air or gas jet towards other people.

Never use air or compressed inert gas to clean clothes.

Before working on the pump, take measures to prevent an uncontrolled start. Put a warning board on the starting device with the words:

"Machine under repair: do not start".

With electric drive equipment, lock the main switch open and withdraw any fuses. Put a warning board on the fuse box or main switch with the words:

"Machine under repair: do not connect".

Never clean equipment with inflammable solvents or carbon tetrachloride. Protect yourself against toxic fumes when using cleaning agents.

6.2 Maintenance schedule



It is recommended that a maintenance plan and schedule is adopted, in line with these User Instructions, to include the following:

- a) Any auxiliary systems installed must be monitored, if necessary, to ensure they function correctly.
- b) Gland packings must be adjusted correctly to give visible leakage and concentric alignment of the gland follower to prevent excessive temperature of the packing or follower.
- c) Check for any leaks from gaskets and seals. The correct functioning of the shaft seal must be checked regularly.
- d) Check bearing lubricant level, and if the hours run show a lubricant change is required.
- e) Check that the duty condition is in the safe operating range for the pump.
- f) Check vibration, noise level and surface temperature at the bearings to confirm satisfactory operation.
- g) Check dirt and dust is removed from areas around close clearances, bearing housings and motors.
- h) Check coupling alignment and re-align if necessary.

Our specialist service personnel can help with preventative maintenance records and provide condition monitoring for temperature and vibration to identify the onset of potential problems.

If any problems are found the following sequence of actions should take place:

- a) Refer to section 7, *Faults; causes and remedies*, for fault diagnosis.
- b) Ensure equipment complies with the recommendations in this manual.
- c) Contact Flowserve if the problem persists.

6.2.1 Routine inspection (daily/weekly)



The following checks should be made and the appropriate action taken to remedy any deviations:

- a) Check operating behaviour. Ensure noise, vibration and bearing temperatures are normal.
- b) Check that there are no abnormal fluid or lubricant leaks (static and dynamic seals) and that any sealant systems (if fitted) are full and operating normally.

- c) Check that shaft seal leaks are within acceptable limits.
- d) Check the level and condition of oil lubricant. On grease lubricated pumps, check running hours since last recharge of grease or complete grease change.
- e) Check any auxiliary supplies such as heating/cooling (if fitted) are functioning correctly.



Refer to the manuals of any associated equipment for routine checks needed.

6.2.2 Periodic inspection (six monthly)



- a) Check foundation bolts for security of attachment and corrosion.
- b) Check pump running records for hourly usage to determine if bearing lubricant requires changing.
- c) The coupling should be checked for correct alignment and worn driving elements.



Refer to the manuals of any associated equipment for periodic checks needed.

6.2.3 Re-lubrication

Lubricant and bearing temperature analysis can be useful in optimizing lubricant change intervals. In general however, the following is recommended.

6.2.3.1 Grease lubrication




See section 5.2.2 for grease recommendations.

Regrease - via grease nipples every 2 000 hours or sooner depending on the severity of the application.

It is important not to under or over grease the bearings as this will lead to overheating and premature failure.

- a) Grease lubricated bearing housings have grease nipples fitted in the bearing covers.
- b) Move the axial seal ring back so the gap between the pump shaft and bearing cover can be seen.
- c) Connect grease gun to the nipple.
- d) Press grease into the bearing housing until the first signs of it appear in the gap between the housing and shaft, then stop greasing.
- e) The maximum allowable operating temperatures for anti-friction bearings will vary from unit to unit, depending on ambient and fluid temperature. The rise above ambient should not normally exceed 55 °C (131 °F) or a combined maximum of 95 °C (204 °F).
- f) A continuously rising temperature or an abrupt temperature rise indicates a problem. If these

symptoms occur, stop the pump immediately and investigate the cause.



Grease change - every 4 000 hours or sooner depending on the severity of the application.

- a) Remove the bearing housing from the rotor assembly.
- b) Brush the bearing housing with hot kerosene (100 to 115 °C/212 to 240 °F) or other non-toxic solvent.
- c) Clean and flush out the housing with a light mineral oil.
- d) Do not use waste oil to clean the housing.

To clean the bearings:

- a) Wipe off as much grease as possible with a clean lint-free cloth.
- b) Brush bearings with hot kerosene (80 to 90 °C/ 175 to 195 °F) while gently spinning the outer bearing ring.
- c) Spin each ball to ensure that it is clean.

To remove badly oxidized grease which refuses to come off:

- a) Support the rotor in a vertical position and immerse the bearing in hot kerosene or a mixture of alcohol and light mineral solvent.
- b) Gently spin the bearing outer ring.
- c) Dry and re-flush the bearing with clean light oil.
- d) It is important not to under or over grease the bearings as this will lead to overheating and premature failure. It is recommended that the bearings be filled with grease using a suitable spatula. In addition, the housings should be no more than half filled.

6.2.3.2 Oil lubrication



Maintaining the correct oil level is very important.

If the pump is supplied with a constant level oiler the oil level will be automatically maintained and as long as oil is visible in the glass bottle there is no need to refill. If a sight glass has been fitted, then regular checks should be made to ensure the level is maintained at the centre of the glass window.

Refer to section 5.1.1 for methods of oil fill, section 5.2.1 for oil grade recommendations and 5.2.4 for the schedule and temperature limits.

6.2.4 Mechanical seals

No adjustment is possible. When leakage reaches an unacceptable level, the seal will need replacement.

6.2.5 Gland packing

The stuffing box split gland can be completely removed for re-packing or to enable the addition of extra rings of packing.

The stuffing box is normally supplied with a lantern ring to enable a clean or pressurised flush to the centre of the packing. If not required, this can be replaced by an extra 2 rings of packing.

There must always be a small leakage, normally a minimum of 120 drops per minute to atmosphere to lubricate and cool the packing is required.

6.3 Spare parts

6.3.1 Ordering of spares

Flowserve keep records of all pumps that have been supplied. When ordering spares, the following information should be quoted:

- 1) Pump serial number
- 2) Pump size and type
- 3) Part name – taken from section 8
- 4) Part number – taken from the job sectional or section 8
- 5) Number of parts required

The pump size and serial number are shown on the pump nameplate.

To ensure continued satisfactory operation, replacement parts to the original design specification should be obtained from Flowserve.

Any change to the original design specification (modification or use of a non-standard part) will invalidate the pump's safety certification.

6.3.2 Storage of spares

Spares should be stored in a clean dry area away from vibration. Inspection and re-treatment of metallic surfaces (if necessary) with preservative is recommended at 6 monthly intervals. Rubber components must be protected from direct sunlight and heat as some rubbers are affected by ozone.

6.4 Recommended spares and consumable items

For start-up purposes:

- 1 - complete set of gland packing
- 2 - shaft sleeves
- 1 - set of gaskets and seals
- (optional: 2 - mechanical seals)

For 2 years operation:

- 1 - set of bearings (line and thrust)
- 2 - sets of gland packing
- 2 - shaft sleeves
- 2 - sets of gaskets and seals
- 2 - lantern rings
- 2 – sets of rubber liners
- (optional: 2 - mechanical seals)

For 4 years operation:

- 1 - set of bearings (line and thrust)
- 2 - sets of gland packing
- 2 - shaft sleeves
- 2 - sets of gaskets and seals
- 2 - lantern rings
- 2 – sets of rubber liners
- 1 - impeller
- (optional: 2 - mechanical seals)

6.5 Tools required

A typical range of tools that will be required to maintain these pumps is listed below.

Readily available in standard tool kits, and dependent on pump size:

- Open ended spanners (wrenches) to suit up to M 48 screws/nuts
- Socket spanners (wrenches), up to M 48 screws
- Allen keys, up to 10 mm (A/F)
- Range of screwdrivers
- Soft mallet

More specialized equipment:

- Bearing pullers
- Bearing induction heater
- Dial test indicator
- C-spanner (wrench) - for removing shaft nut. (If difficulties in sourcing are encountered, consult Flowserve.)

6.6 Fastener torques

Bolt size	Torque Nm (lb•ft)	
	Pump feet fasteners	All other fasteners
M 16 (5/8 in.)	170 (125)	84 (62)
M 20 (3/4 in.)	340 (250)	165 (120)
M 24 (7/8 in.)	590 (435)	285 (210)
M 27 (1 in.)	770 (570)	375 (275)
M 30 (1 1/8 in.)	1 100 (810)	540 (400)
M 36 (1 3/8 in.)	1 840 (1 350)	900 (660)
M 42 (1 7/8 in.)	2 000 (1 475)	1 410 (1 040)
M 48 (1 7/8 in.)	2 240 (1 650)	2 060 (1 500)

TIGHTENING TORQUE FOR STAINLESS STEEL STUDS WITH LUBRICATED THREADS		
THREAD SIZE	TIGHTENING TORQUE	
	Nm	ft. lbs.
M10x1.5 (3/8-16UNC)	13	10
M12x1.75 (1/2-13UNC)	27	20
M16X2 (5/8-11UNC)	60	45
M20x2.5 (3/4-10UNC)	100	75

6.7 Renewal clearances

As wear takes place between the impeller and casing liners the overall efficiency of the pump set will decrease. To maintain optimum performance, it is recommended that the impeller clearance be reset. Some services will dictate that adjustments be performed regularly. Excessive clearance will induce greater recirculation and accelerate the rate of wear. The liners or impeller must be replaced when there is no more adjustment capability in the bearing housing. Leakage at the liner mounting studs and/or flange joints may indicate that the liner has holed.

6.8 Disassembly

Refer to section 1.6, *Safety*, before dismantling the pump.

Before dismantling the pump for overhaul, ensure genuine Flowserve replacement parts are available.

To disassemble the pump, consult the job sectional drawing, general sectional drawing (see section 8), and *Parts list*.

6.8.1 Rotating Element

The following procedure is recommended for removing and disassembling the rotating assembly.

Note that the replacement gaskets and similar

consumable materials should be available since they will be required for reassembly.

- Isolate motor and lock off electrical supply in accordance with local regulations.
- Isolate suction and discharge valves.
- Remove guards
- Disconnect the coupling halves or remove belts from sheaves.
- Drain pump casing. Remove any auxiliary piping if applicable.
- Disconnect stuffing box, cooling water and auxiliary piping.
- Drain the oil from the bearing frame [3130] if bearing frame is being dismantled.
- Disconnect pump from piping and remove spool pieces as necessary.
- Remove pump from baseplate to work on bearing frame.

For pumps fitted with an overhead motor mount it is suggested that the motor be removed.

The remaining steps assume that the pump has been removed.

- Remove suction side casing [1211] from Gland side casing [1212].

6.8.1.1 Expeller Pumps only

- Release the thrust bearing housing [3230] hold down bolts and jam nuts. While rotating the pump shaft [2110] by hand, tighten the three jacking screws evenly until the impeller [2] lightly clamp the expeller housing [4110]. This will simplify withdrawal of the rotating element from the casing.


Excessive clamping force could damage bearing races. Rotating the shaft helps to clear away solids which may be trapped between the impeller and expeller housing.

- Unfasten gland side casing [1212] from the pedestal [3120].
- Remove gland side casing [1212].
- Clamp the expeller Housing to the pedestal to prevent it from accidentally coming loose.

6.8.1.2 Impeller (all pumps)

The impeller is threaded to the shaft and has been self-tightened to the shaft sleeve. To unscrew the impeller the torque must be broken. It will be necessary to either block the impeller or shaft at the drive-end. A fixture similar to that shown in the sketch

may be used. To unscrew the impeller the shaft must be turned counterclockwise.



- a) On small pumps the impeller can be removed and held by hand however, larger units will require that a hoist be used to lift the impeller. Place a sling through the impeller vanes.
- b) Remove the impeller [2200].

6.8.1.3 Expeller Pumps Only

- a) Place a sling around the expeller housing.
- b) Remove c-clamp
- c) Remove expeller [2250].
- d) Remove expeller wear plate [1915].
- e) Remove stuffing box head [4100].

All pumps except expeller option

6.8.2 Stuffing box

6.8.2.1 Shaft seal - gland packing

- a) Remove gland nuts and gland halves [4120]
- b) Remove gland packing rings [4130] and lantern rings [4134] using a bent wire.

6.8.2.2 Shaft seal - mechanical seal



Refer to any special instructions supplied with the mechanical seal.

- a) Remove seal cover screws and pull off seal cover complete with the stationary seal ring that is held in place by the O-ring seal.
- b) The mechanical seal cover can also be removed by placing a wedge into the gland chamfer, as below:

6.8.3 Shaft sleeve

- a) Remove the impeller spacer [2460] and shaft sleeve gasket.
- b) Remove the shaft sleeve [2445] if scored or worn.

6.8.4 Bearing housing

- a) Remove the deflector [2540] and the line bearing cover [3260].
- b) Remove the pump half coupling and coupling key

[6700].

- c) Remove the bearing frame support [3134] and OHMM if applicable.
- d) Lift the bearing frame assembly into a vertical position with the thrust bearing housing [3230] up. Rest the bearing frame flange on heavy wooden blocks sufficiently high to ensure end of the shaft does not come into contact with the floor or table.
- e) Remove the thrust bearing hold down bolts and remove shaft assembly for the bearing frame [3130].

6.8.5 Line bearing

- a) Lay the shaft [2110] horizontal and support with wooden 'V' Blocks.
- b) Only if necessary, remove the line bearing [3011] from the shaft. Bearings removed can easily be damaged and undetected until pump is put back in operation.

6.8.6 Thrust bearings

- a) Lay the shaft [2110] horizontal and support with wooden 'V' Blocks.
- b) Remove the thrust bearing clamp ring [2542] from the thrust bearing housing [3230].
- c) Remove the thrust bearing housing [3230].
- d) Bend up the locking tab on the bearing lockwasher [6541] and remove the bearing locknut [3712] and lockwasher [6541].
- e) Only if necessary, remove the thrust bearings [3031] from the shaft. Bearings removed and reused can easily be damaged and undetected until pump is put back in operation.

Note: On frame 6 there are springs to preload the thrust bearings. These must be removed as the bearings are removed.

6.8.7 Gland side Liner (if necessary)

Note: There are 2 sets of studs. The inner ring secures the stuffing box to the casing and the outer ring secures the liner to the casing. nuts and washers.

- a) Place the gland side casing on a clean work surface resting on the large flange.
- b) Remove the inner ring of hex nuts that secure the stuffing box [4132] to the casing [1212]
- c) Remove the loose box from the casing.
- d) Remove the Protector plate [4132] from the bore of the casing.
- e) Remove the outer ring of nuts that secure the gland side liner [1916.2] to the gland side casing [1D].
- f) If necessary, use wood blocks on the studs or center portion to dislodge the liner.
- g) Lift the casing away from the liner

6.8.8 Suction side Liner (if necessary)

- a) Place the suction side casing on a clean work surface.
- b) Remove the hex nuts that secure the liner to the casing.
- c) Using long bolts in the tapped holes in the center of the casing jack the liner out of the casing.

Note:

Use a pry bar to dislodge the nozzle lip.

- d) Lift the casing away from the liner.

6.9 Examination of parts



Used parts must be inspected before assembly to ensure the pump will subsequently run properly.

In particular, fault diagnosis is essential to enhance pump and plant reliability.

6.9.1 Casing, seal housing and impeller

- a) Inspect for excessive wear, pitting, corrosion, erosion or damage and any sealing surface irregularities.
- b) Replace as necessary.
- c) Inspect the impeller [2200] and the liners [1916.1] and [1916.2] for excessive wear or damage. Remove the liners from the casings [1211 and 1212] if necessary.
- d) Inspect the casing halves [1211 and 1212] and stuffing box [4132 or 4100 for expeller] for damage or excessive thinning of wall sections due to wear or corrosion.
- e) Inspect the protector plate [4132] and impeller spacer [2460] and remove if damaged or worn. Clean the internal bore of the stuffing box.

6.9.2 Shaft and sleeve [if fitted]

- a) Replace sleeve if grooved, pitted or worn.
- b) Clean the shaft and inspect for evidence of corrosion, evidence of cracking, fatigue or mechanical damage. Remove all burrs or nicks paying particular attention to the areas under the lip seals. Check that the shaft is straight within 0.002 inch (0.050 mm).

6.9.3 Gaskets and O-rings

After dismantling, discard and replace.

6.9.4 Bearings

- a) It is recommended that bearings are not re-used after any removal from the shaft.
- b) The plain liquid lubricated bearings may be re-used if both the bearing bush and bearing sleeve show no sign of wear, grooving or corrosion attack. (It is recommended that both the bush and sleeve are replaced at the same time.)

6.9.5 Bearing isolators, labyrinths or lip seals (if fitted)

- a) The lubricant, bearings and bearing housing seals are to be inspected for contamination and damage. If oil bath lubrication is utilised, these provide useful information on operating conditions within the bearing housing.
- b) If bearing damage is not due to normal wear and the lubricant contains adverse contaminants, the cause should be corrected before the pump is returned to service.
- c) Labyrinth seals and bearing isolators should be inspected for damage but are normally non-wearing parts and can be re-used.
- d) Bearing seals are not totally leak free devices. Oil from these may cause staining adjacent to the bearings.

6.10 Assembly

To disassemble the pump, consult the job sectional drawing, general sectional drawing (see section 8), and *Parts list*.

Ensure threads, gasket and O-ring mating faces are clean. Apply thread sealant to non-face sealing pipe thread fittings.

6.10.1 Bearing housing

- a) Lubricate the internal bores of the bearing frame [3130] with the same oil or grease used to lubricate the bearings.
- b) Install the thrust bearing housing [3230] in the bearing frame [3130] to ensure a good sliding fit. Remove the thrust bearing housing from the frame.
- c) Install the oil sight gauge [3856] and the drain lug in the bearing frame [3130] using Teflon pipe thread sealant. Install the vent plug [6578].

6.10.2 Line bearing

- a) Lightly lubricate the shaft [2110] at the line bearing position. Install the line bearing [3011] on the shaft. Use an induction heated or hot oil bath to first heat the bearing [250° F recommended], press the bearing on shaft with the aid of a sleeve designed to push the inner race only. Note that the bearing must remain square to the shaft during assembly and that the inner race must seat on the shaft shoulder.
- b) Pack the line bearing with grease if the bearings are being grease lubricated.
- c) Protect the bearing by wrapping with a clean, lint free cloth.

6.10.3 Thrust bearing

6.10.3.1 Frames 1, 2 & 3


- a) Place the thrust bearing clamp ring [2542] loosely over the shaft on the largest diameter.

- b) Install the angular contact bearings [3031] on the shaft [2110] using the same procedure as described in step 6.10.2. The bearings are mounted back to back as shown.
- c) Pack thrust bearing with grease if the bearings are being grease lubricated.
- d) Slide the bearing lockwashers [6541] on the shaft and fit the bearing locknut [3712]. Tighten the locknut snugly and allow to cool. Check the tightness and bend one tab on the lockwasher into a slot in the locknut. Protect the bearings from contamination.
- e) Carefully install the lip seal [4300] in the thrust bearing housing [3230] by pressing it squarely into the bore. The primary sealing lip [spring loaded] on seal should be installed facing the bearing. A small amount of sealant may be applied on the O.D. of the seal prior to its installation.
- f) Install the square head plug or grease fitting on the

even all around. Tighten in accordance with Table 6.6.

6.10.3.2 Frame 4 pumps

- a) Place the thrust bearing clamp ring [2542] loosely over the shaft on the largest diameter.
- b) Install the 4-point angular contact bearing [3031] on the shaft [2110] using the same procedure as described in step 6.10.2 and ensure it is seated against the shoulder.
- c) Install the NU-roller bearing.
- d) Slide the bearing lockwashers [6541] on the shaft and fit the bearing locknut [3712]. Tighten the locknut snugly and allow to cool. Check the tightness and bend one tab on the lockwasher into a slot in the locknut. Protect the bearings from contamination.
- e) Pack bearing with grease if the bearings are being grease lubricated.
- f) Carefully install the lip seal [4300] in the thrust bearing housing [3230] by pressing it squarely into the bore. The primary sealing lip [spring loaded] on seal should be installed facing the bearing. A small amount of sealant may be applied on the O.D. of the seal prior to its installation.
- g) Install the square head plug or grease fitting on the tapped hole in the thrust bearing housing flange. Lubricate the o-ring [4610] with the bearing lubricant and assemble it into the groove of the outer circumference of the thrust bearing housing [3230].
- h) Lubricate the inside bore of the thrust bearing housing [3230] and assemble it over the thrust bearings. Care must be taken to prevent damage of the seal on the shaft.
- i) Using cap screws and lockwashers, attach the thrust bearing clamp ring [2542] to the thrust bearing housing [3230]. Lock the threads using Loctite 242 or equivalent.



tapped hole in the thrust bearing housing flange. Lubricate the o-ring [4610] with the bearing lubricant and assemble it into the groove of the outer circumference of the thrust bearing housing [3230].

- g) Lubricate the inside bore of the thrust bearing housing [3230] and assemble it over the thrust bearings. Care must be taken to prevent damage of the seal on the shaft.
- h) Using cap screws and lockwashers, attach the thrust bearing clamp ring [2542] to the thrust bearing housing [3230]. Lock the threads using Loctite 242 or equivalent.


Note:

The thrust bearing clamp ring [2542] is provided with one extra hole midway between two adjacent bolt holes to permit free oil flow. On oil lubricated units, this hole must align with the cast oil return at the bottom of the thrust bearing housing bore. For grease lubricated units, this hole should be oriented away from the cast oil return slot at the bottom the thrust bearing housing bore.

Tighten the cap screws evenly ensuring that the clamp ring is not distorted and gap to the bearing housing is

6.10.3.3 Frame 6

- a) Place the shaft in a vertical position such that the coupling end is up.
- b) Lightly lubricate the shaft [2210] at the thrust bearing position.



- c) Install the inner race of one of the spherical roller thrust bearing [3031] on the shaft. Use an induction heater or hot oil bath to first heat the bearing (250 F recommended), press the bearing on the shaft with the aid of a sleeve designed to push the inner race only. Note that the bearing must remain square to the shaft during assembly and that the inner race must seat on the shaft shoulder.
- d) Install the rollers and outer race onto installed inner race.
- e) Place the thrust bearing clamp ring [2542] on top of the bearing installed.
- f) Insert the springs [4260] into the holes provided in the clamp ring.
- g) Install the outer race of the second spherical roller thrust bearing [3031] on top of the assembly. Place spacer shims, 0.25mm (0.010 in.) between the clamp ring and one of the bearing outer races. Centralize the loosely assembled bearing components. Using 2 c-clamps or similar devices compress the springs in the clamp ring.
- h) Install the remaining inner bearing race using the same procedure as above.
- i) Install the bearing spacer [2460].
- j) Install the radial bearing.
- k) Slide the bearing lock washers [6541] on the shaft and fit the bearing locknut [3712]. Tighten the locknut snugly and allow the bearings to cool. Check the tightness. Before securing the lockwasher tab, remove the spacer shims from the clamp ring. Bend one tab on the lockwasher into a slot in the locknut. Protect the bearings from contamination.
- l) Carefully install the lip seal [4300] in the thrust bearing housing [3230] by pressing it squarely into the bore. The primary sealing lip (spring loaded) on seal should be installed facing the bearing. A small amount of sealant may be applied on the O.D. of the seal prior to its installation.

- m) Lubricate the inside bore of the thrust bearing housing [3230] and assemble it over the thrust bearings. Care must be taken to prevent damage of the seal on the shaft.

6.10.4 Frame assembly

6.10.4.1 Frame 1 & 2

- a) Place the pedestal with the large flange flat on a work surface/table.
- b) Lift the bearing cartridge vertical and assemble to the pedestal. Secure in position.


Note:

The orientation of the pedestal feet and the tapped holes for the rear support foot should be aligned.

- c) Place the assembly so that the shaft when installed will clear the table or work surface. The assembly may be elevated if necessary.
- d) Lift the shaft assembly into a vertical position (the coupling end of the shaft is tapped for a lifting bolt).
- e) Lower it into the bearing frame [3130]. Note the square head plug (or grease fitting in the thrust bearing housing [3230] must align with the vent lug [6580] in the frame [3130].
- f) Install jacking and hold down hardware.
- g) Place assembly horizontal and rest on pedestal feet.
- h) Install rear support foot for stability.

6.10.4.2 Frame 3 & 4

- a) Place the shaft assembly in a vertical position with the thrust bearing housing [3230] resting on the flange face and supported by blocks or clamps. Access to one through hole in the thrust bearing housing is required to attach one bolt.




- b) Lift the bearing frame assembly [3130] vertically and lower over the shaft assembly. Manually guide the line bearing outer race into the bearing

- c) Install at least one thrust bearing housing to bearing frame hold down cap screws complete with lockwasher to prevent the assembly from coming apart when lifting.
- d) Place the bearing frame assembly into a horizontal position.
- e) Install the remaining cap screws and lockwashers. Assemble the jam nuts on the jacking screws and assemble these into the thrust bearing housing [3230].
- f) Place pedestal on its feet.
- g) Install cartridge assembly into the pedestal. Secure with appropriate hardware.
- i) Install rear support foot for stability.

6.10.4.3 Frame 6

- a) Place the shaft assembly in a vertical position with the thrust bearing housing [3230] resting on the flange face. The shaft should be supported in a fixture for safety and to prevent damage. Access to one hole in the thrust bearing housing [3230] is required to attach one bolt.



- b) Install the gasket [4590] onto the housing flange.
- c) Lift the bearing cartridge [3130] vertically and lower over the shaft assembly. Manually guide the line bearing outer race into the bearing cartridge bore. The thrust bearing housing [3230] and cartridge [3130] are orientated to ensure that the oil return slot in the thrust bearing housing [3230] is properly located.
- d) Install at least one thrust bearing housing to bearing frame hold down cap screw complete with lockwasher to prevent the assembly from coming apart when lifting.
- e) Install oil site gauge [3856] and plugs inside of bearing cartridge [3130].

- f) Place the bearing frame assembly into a horizontal position and mount unto the pedestal rails.
- g) The pedestal rails have sets of holes that will be used to lock the pedestal in position. The outer holes will be used for initial installation.

Note:

- As the pump wears in service and the impeller is readjusted the inner holes will be exposed and the hold-down bolts will have to be moved.
- h) Install the remaining hold down cap screws and lockwashers into the bearing housing [3230].
- i) Install the cartridge hold down bolts with the heavy plate washers but do not tighten.
- j) Install the adjusting screw [6576] between the ribs of the bearing cartridge [3130]. The fixture may be installed on either side of frame as convenient for the installation.

6.10.5 Line Bearing Cover

6.10.5.1 Frames 1-4

- a) Carefully install the lip seal [4300] in the line bearing cover [3260] by pressing it squarely into the bore. The primary sealing lip [spring loaded] on seal should be installed facing the bearing. A small amount of sealant may be applied on the O.D. of the seal prior to its' installation.
- b) Lubricate the o-ring [4610] and assemble into the groove of the line bearing cover.
- c) Assemble the line bearing cover [3260] over the shaft and squarely into the bearing frame bore. Fasten to the bearing frame with cap screws, washers and hex nuts. Tighten firmly, but not excessively.
- d) Assemble the deflector [2540] loosely over the shaft but do not tighten the setscrews.
- e) Install the coupling key [6700] and tape to the shaft.
- f) Rotate the shaft and check that run-out does not exceed 0.050 mm (0.002 inch).

6.10.5.2 Frame 6

- a) Install the lip seal [4300] into the line bearing cover [3260].
- b) Assemble the gasket [4590] onto the face of the line bearing cover [3260].
- c) Assemble the line bearing cover [3260] over the shaft and squarely into the bearing frame bore. Fasten to the bearing frame with cap screws, washers and hex nuts. Tighten firmly but not excessively.
- d) Assemble the deflector [2540] with a slight gap such that it does not rub when shaft is rotated.
- e) Install the coupling key [6700] and tape to the shaft.
- f) Mount a dial indicator to the bearing frame [3130] and indicate shaft under bearing frame flange (approx. mid way between impeller mounting face and end of sleeve area. Rotate shaft and check that

runout does not exceed 0.002 inch (0.050 mm).

6.10.6 Stuffing box

6.10.6.1 Stuffing Box 1.25R090

- a) Place the gland side liner [1916.2] face down on a clean work surface.
- b) Install the stuffing box bushing [4132] onto the liner.

Note: The fit of the bushing is interference in order to hold the liner and bushing together and to ensure a seal.

- c) Orient the flush ports in the bushing in line with the discharge neck and flange.
- d) Place the casing [1212] on the work surface with volute section facing up.
- e) Lift liner [1916.2] and install into casing [1212].

6.10.6.2 All sizes 2.5R and larger

- a) Install the gland studs [6572] using Loctite grade A or equivalent into the stuffing box [4130 or 4132]. Install the square head plugs [6578] in the stuffing box as required using pipe sealant.
- b) Install the shaft sleeve onto the shaft. The hock type sleeve must be seated against the shaft shoulder. Application of Loctite is not necessary as impeller tightening torque during operation is sufficient to ensure sleeve rotation.

6.10.6.3 Standard packing Frames 1-6

- a) Place the gland side liner stud side up on a clean work surface.
- b) Install appropriate studs. The inner studs are longer to mount the loose stuffing box [4132].
- c) Lift the gland side casing [1212] and lower onto the liner.
- d) Secure outer studs with washers and hex nuts.
- e) Install the protector plate [4132] in the bore of the casing and seat against the liner.
- f) Install o-ring into face of stuffing box [4132]. Use a small grease to hold the o-ring.
- g) Install the stuffing box into the casing and align the studs.

Note: The flush ports need to be orientated. Review installation for any particulars. Normally the ports will be aligned at 2 o'clock and 4 o'clock.

- h) Secure with washers and nuts.

6.10.6.4 Gland Side Casings

6.10.6.4.1 All sizes

- a) Lift the casing [1212] and install to the pedestal [3120].
- b) Secure casing to pedestal.

6.10.6.4.2 Frame 6 only

Note: The babbit fits of the gland side casing to the pedestal and to the stuffing box are loose. It is necessary check the concentricity of the stuffing box and the shaft with dial indicators or feeler gauges. If necessary, loosen studs and reposition stuffing box and or the gland side casing. These parts may be dowelled for subsequent maintenance.

Pedestal:

- a) After alignment has been achieved, retighten bolts.
- b) The pedestal has been predrilled for 2 #8 tapered dowel pins. Drill and ream the casing/pedestal using the pilot holes in the pedestal as a jig.

Note: #8 tapered dowels are nominally 12.7mm (0.500in.) with 0.0208 (mm/mm or in./in.) taper.

- c) Fit dowels and ensure all bolts are secure.

Stuffing box:

- a) When centered, tighten bolts and remove gland side casing.
- b) The stuffing box is predrilled 7.94mm (0.3125 in.) for two dowel pins, it will be necessary to re-drill stuffing box and casing together. Drill for a 3/8" straight dowel.
- c) Fit dowels and retighten all nuts.
- d) Reassemble casing to pedestal.

6.10.6.5 Optional expeller seal-frame 1 & 2

- a) Assemble the stuffing box [4100] over the sleeve [2445] and into the bearing frame [3130] register. Orient the grease fitting to suit the installation. Note that if the optional solid gland with lip seal design is used, it must be installed first.
- b) Install O-ring onto the expeller stuffing box. Install expeller wear plate [1915] onto the stuffing box.

Note: Some units may be built with a 1 pc stuffing box/wear plate. In this cause this step will be eliminated.

- c) Install the expeller [2250] over the shaft sleeve. Expeller should seat against the sleeve shoulder but be clear of the expeller wear plate [1915]. Adjust the shaft [2110] forward to ensure that the expeller [2250] when installed will not bind against the stuffing box head [4100].
- d) Install gasket [4590] over expeller to face of stuffing box [4100].
- e) Install expeller housing [4110] to stuffing box [4132], clamp in place.

6.10.6.6 Optional expeller seal-frame 3 & 4

- f) Assemble the stuffing box [4100] over the sleeve [2445] and into the bearing frame [3130] register. Orient the grease fitting to suit the installation. Note that if the optional solid gland with lip seal design is used, it must be installed first.
- g) Install O-ring onto the expeller stuffing box groove. Install expeller wear plate [1915] onto the stuffing box.

Note: Some units may be built with a 1 pc stuffing box/wear plate. In this cause this step will be eliminated.

- h) Install the expeller [2250] over the shaft sleeve. Expeller should seat against the sleeve shoulder but be clear of the expeller wear plate [1915]. Adjust the shaft [2110] forward to ensure that the expeller [2250] when installed will not bind against the stuffing box head [4100].
- i) Install gasket [4590] over expeller to face of stuffing box [4100].
- j) Install expeller housing [4110] to stuffing box [4100], clamp in place.

6.10.6.7 All Expeller fitted Units

- a) The face of the expeller housing [4110] has a recess cut that seats against the gland side liner. To assist with sealing apply a bead of silicone to this recess.
- b) Lift casing [1212] and liner and install over the expeller housing [4110].
- c) Secure to pedestal [3120].

6.10.7 Impeller Installation-all pumps

- a) Install the impeller gasket [4590] on all pumps.
- b) Install the impeller spacer [2460].
- c) Due to the method of assembling the impeller, it is recommended to smear the sleeve face and both sides of the impeller spacer [2460] with a heavy grease or a silicon sealant before assembling onto the shaft which will help to hold the impeller spacer in position during assembly.
- d) Apply anti-seize compound to the shaft threads and screw the impeller onto the shaft. For large sizes it is more practical to hold impeller using a sling and hoist and turn the shaft.

CAUTION Failure to tighten the impeller [2200] spacer [2460] securely against the sleeve may cause serious damage to pump components.

Note: The thread is designed so that during operation the impeller will tend to tighten onto shaft. Therefore, a clockwise shaft rotation (looking from coupling end) will screw impeller on.


- e) Release the thrust bearing housing hold down bolts

and tighten the jacking screws to pull the impeller back to the stuffing box head [4100]. The stuffing box head must not be rigidly clamped.

6.10.8 Suction Side Liner

6.10.8 1.25R090

- a) Place casing [1211] on clean work surface with the casing resting on the suction flange.
- b) Lift liner and install into casing.



Note: The 1.25R090 does not use bolts to hold the liner in place.

6.10.8.2 12R264 and 18R416 with 2 pc liner

- a) Place the suction side liner [1916] for 2 pc liners on 12R264 and 18R416] on a clean work surface with support plate (stud holes exposed)
- b) Install the studs [6572] in the suction side liner [1916.1] using Loctite grade A or equivalent.
- c) Smear the suction nozzle and volute wall with a liquid soap (do not use petroleum product as it can swell some rubbers.
- d) Lift suction side casing [1211] and install over liner [1916]. The sealing lip of the suction nozzle must be pried into position. Use a blunt pry bar in a way similar to installing a tire on a rim. Once nozzle is in place, fasten liner.

6.10.8.3 All Sizes 2.5 and larger

- a) Place the Suction side inner liner [1916] on a clean work surface and elevate such that back of the liner is higher than volute depth of the outer liner [1916]
- b) Install studs into liner [1916].
- c) Smear the suction nozzle and outside diameter of the liner with a liquid soap (do not use petroleum product as it can swell some rubbers.
- d) Lift suction side casing [1211] and install over liner [1916]. The sealing lip of the suction nozzle must be pried into position. Use a blunt pry bar in a way similar to installing a tire on a rim. Once nozzle is in place, fasten liner.

6.10.9 Casing

- a) Install dowel pins in gland side casing.
- b) Lift the suction side casing [1211] and assemble to the gland side casing [1212].
- c) Pumps with 8" discharge and larger use spacers between the casing halves. Install mounting hardware.

Note: Spacers required for pumps 8" and larger

- d) Secure into position. Ensure that the impeller is free to rotate before torquing bolts.
- e) Set the impeller front clearance in accordance with instruction earlier in this section of the manual.

6.10.10 Shaft seal

6.10.10.1 Packing


- a) The two-piece lantern ring [4134] must be installed first for standard L5. Push the lantern ring and previously installed packing. The ports in the lantern ring do not need to be aligned with the inlet/outlet ports.
- b) Insert one packing ring at a time into the stuffing box. Push the packing as far as possible into the packing bore.

Standard Packed Box Arrangement (frame 1-4)

- c) Install additional rings as required, staggering the joints.
- d) Ensure that the shaft can be turned by hand.
- e) Install the remaining rings of packing, alternating the joints.

Note: It may not be possible to insert the last ring in the box and still insert the gland. In this case, omit the last ring of packing and install the gland.

The last ring of packing should be installed after the pump has been in service and sufficient space is available.



Standard Packed Box Arrangement (1.25R090)

- f) Install the gland halves [4120], tighten the gland nuts [6580] only finger tight.

CAUTION New packing has to be run-in and it is good practice to start the pump with the stuffing box gland quite loose. Packing that is too tight in the box will cause undue friction, creating heat which will glaze the packing and possibly score the shaft sleeves. To be effective, the packing must remain soft and pliable. If stuffing box friction is so great that the pump shaft cannot be turned by hand, the box is not properly packed.

6.10.10.2 Mechanical seal

These details are specific to non-cartridge seals therefore they may not apply. Refer to any special instructions supplied with the mechanical seal.

- a) Before the mechanical seal can be installed, the pump must be assembled with the correct impeller running clearances (ie: all assembly steps above). A scribe mark is then placed on the circumference of the sleeve to mark the end of the box. This mark is used to locate the seal position referenced by the mechanical seal drawing provided.
- b) After scribing the sleeve, remove the rotating element from the casing. Do not adjust the bearing housing.
- c) Remove the impeller [2200] and gland side casing [1212]. Assemble the mechanical seal components, including gland plates, gaskets and rotating parts over the sleeve. Locate the seal relative to the scribed markings on the shaft sleeve [2445] as indicated by the seal manufacturers' instruction.
- d) Assemble the mechanical seal gland plate and gasket and fasten using gland studs [6572]. Secure with nuts [6580] and tighten each by hand. Further tighten the nuts in accordance with Table in 6.6. Rotate the shaft to ensure that it turns freely without rubbing or binding.
- e) Re-assemble the rotating element into the casing. Do not adjust the thrust bearing housing.
- f) Set the deflector [2540] at the line bearing cover [3260] so that they do not contact when the shaft is rotated. Lock in place with the setscrews provided.

6.10.11 Final assembly

- a) Lift the assembled pump onto the baseplate and position the pedestal feet over the tapped holes in the baseplate.
- b) On frame sizes 1 to 4, loosen the bolts that attach the rear support foot [3134] to the bearing frame [3130]. Level the unit and align with the piping. Tighten the bolts attaching the casing feet to the baseplate in accordance with Table 6.6 using for tightening torques. Do not distort pedestal or frame.
- c) Install the pump coupling or sheave as required.


- d) Refer to Section 4, Installation and Section 5, Preparation for Operation.
- e) It is recommended that the pump not be packed until required. Refer to stuffing box packing procedure in this section. Protect the stuffing box bore and seal area with clean dry rags.

6.11 Impeller axial clearance adjustment

Note: This procedure should not be used on units with mechanical seals if the design is such that a liquid seal cannot be maintained when the rotor is moved axially against the liners.

CAUTION A blind flange must be installed on the suction to compress the liner nozzle as it will be in service. If this is not done clearance could be lost cause impeller to rub against the liner causing damage to pump components.

NEVER ATTEMPT TO CHANGE THE CLEARANCE WHEN THE PUMP IS RUNNING.



6.11.1 Frames 1-4

If the coupling has limited axial adjustment capability, the pump and driver must be uncoupled prior to adjusting the clearance in order to permit free movement.

CAUTION Install blind flange or pipe spool on suction.

- a) Loosen the two set screws retaining the deflector [2540] and check that the deflector is free to move axially on the shaft.
- b) Loosen the thrust bearing housing jam nuts and back off the three jacking screws at least 1.5 mm (0.060 inch).
- c) Move the rotor towards the suction side liner [1916.1] by tightening the three hold-down cap screws evenly and uniformly until the impeller [2200] just touches the liner. This can be best

established by rotating the shaft and stopping the forward motion at the first sign of rubbing. If the shaft cannot be rotated, back off the bearing housing with the jacking screws until a just detectable rub is obtained. Check that the gap between the two machined faces of the thrust bearing housing [3230] and the bearing frame [3130] are parallel within 0.076 mm (0.003 inch). Adjust the jack screws and hold down cap screws as required to achieve this parallelism. When the impeller [2200] just touches the liner [1915] and the thrust bearing housing [3230] is parallel to the bearing frame [3130] the axial clearance between the impeller and wear plate is zero.

6.11.1.1 Option1

- a) Place a dial indicator, set to end of shaft [2110] or on housing [3230] face.
- b) Set indicator reading to zero (0).
- c) Note required impeller clearance.

6.11.1.2 Option 2

- a) Measure and record the axial gap between the thrust bearing housing flange and bearing frame end face. Determine the required impeller axial running clearance from Section 3 and add this to the above measurement to establish the required gap setting.

6.11.1.3 Setting Axial Clearance

- a) Loosen the thrust bearing housing hold down cap screws slightly and tighten the jack screws. Until the required dial indicator reading (6.11.1.1) or housing gap reading (6.11.1.2) is achieved.
- b) Alternately and gradually tighten the hold down cap screws and jack screws until the required gap setting is achieved at each hold down cap screw location. Note that the gap at each jack screw will be slightly larger as a result of minor elastic distortion of the thrust bearing housing flange caused by the high pre-load forces. The gap setting at any set of screws must be the same within 0.076 mm (0.003 in.). Careful attention to this procedure will help ensure long thrust bearing life.
- c) While preventing the jack screws from rotating, tighten the jam nuts to lock them in position.
- d) Adjust the axial position of the deflector [2540] so that it is clear of the line bearing cover [3260] by approximately 0.75 mm (0.030 in.) and tighten the setscrews (if present) firmly. Excessive tightening may mar the shaft.
- e) Manually rotate the shaft to ensure that there is no rubbing or binding.
- f) On belt driven units, adjust the pump or driver sheave to maintain belt alignment. (Refer to Section 4.5.2.2).

- g) Check the alignment on direct driven units (refer to Section 4) and reassemble the coupling components.
- h) Replace any safety guards which may have been removed.


6.11.2 Frame 0

If the coupling has limited axial adjustment capability, the pump and driver must be uncoupled prior to adjusting the clearance in order to permit free movement.



Install blind flange or pipe spool on suction.

- a) Slide the rubber deflector [2540] away from the face of the bearing frame.



- b) Loosen the thrust bearing housing Jacking Nut.
- c) Move the rotor towards the suction side liner [1916.1] by tightening the hold-down nut until the impeller [2200] just touches the suction side liner [1916.1]. This can be best established by rotating the shaft and stopping the forward motion at the first sign of rubbing. If the shaft cannot be rotated, back off the bearing housing with the jacking screws until a just detectable rub is obtained. When the impeller [2200] just touches the suction side liner [1916.1] the axial clearance between the impeller and wear plate is zero (0).

6.11.2.1 Option 1

- d) Place a dial indicator, set to end of shaft [2110] or on housing [3230] face.
- e) Set indicator reading to zero (0).
- f) Note required impeller clearance.

6.11.2.2 Option 2

- b) Measure and record the axial gap between the thrust bearing housing flange and bearing frame end face. Determine the required impeller axial running clearance from Section 3 and add this to

the above measurement to establish the required gap setting.

6.11.2.3 Set Axial Clearance

- d) Loosen the thrust bearing housing hold down nut slightly and tighten the jacking nut. Until the required dial indicator reading (6.11.2.1) or housing gap reading (6.11.2.2) is achieved.
- e) Tighten the hold down nut.
- d) Adjust the axial position of the deflector [2540] so that it is clear of the line bearing cover [3260] by approximately 0.75 mm (0.030 in.)
- e) Manually rotate the shaft to ensure that there is no rubbing or binding.
- f) On belt driven units, adjust the pump or driver sheave to maintain belt alignment. (Refer to Section 4.5.2.2).
- g) Check the alignment on direct driven units (refer to Section 4) and reassemble the coupling components.
- h) Replace any safety guards that may have been removed.

6.11.3 Frame 6

NEVER ATTEMPT TO CHANGE THE CLEARANCE WHEN THE PUMP IS RUNNING.

If the coupling has limited axial adjustment capability, the pump and driver must be uncoupled prior to adjusting the clearance in order to permit free movement. Before doing so, ensure that the impeller is free to rotate. Settled slurry will make impeller adjustment difficult. The casing may have to be flushed to remove heavy slurry.

- a) Loosen the eight (8) cartridge hold down bolts located on the side of the cartridge [3130].
- b) Move the cartridge towards the pump suction by adjusting the screw on the adjusting assembly that is mounted on the pedestal between adjacent ribs until the impeller makes contact with the suction side liner [1916.1]. It is advisable to rotate shaft/impeller while making the adjustment as the first sign of contact will signify zero clearance. If the impeller cannot be rotated the cartridge should be adjusted backwards until the impeller is just making contact. Place a dial indicator on to the shaft end or bearing cartridge and set indicator to zero (0).
- c) Determine the required impeller axial running clearance from Section 3 and add this to the above measurement to establish the required gap setting. Adjust the cartridge/shaft away from the casing until the desired reading is achieved.
- d) Tighten the hold down bolts on the cartridge side

- flanges in accordance with tables in 6.6.
- e) Manually rotate the shaft to ensure that there is no rubbing or binding.
- f) On belt driven units, adjust the pump or driver sheave to maintain belt alignment.

6.12 Liner Mismatch

When two liners come together some mismatch is expected.


6.12.1 Axial Split

- a) Mismatch along this axial split between the liner halves is acceptable and no rework is necessary.

- b) This mismatch is parallel to the flow and will not cause hydraulic or mechanical problems.
- b) On pumps with 8" or larger the compressed lip outside the casing in the area of the spacers should be relatively aligned within 10mm (0.38in.). If both lips are not visible the casings should be separated and liners re-seated.


6.12.2 Discharge Flange

- a) Some mismatch can be tolerated. The harder the rubber the less mismatch that can be permitted.
- b) Generally, if the mismatch exceeds 1.5mm (0.06in.) then the joint should be dressed.



CAUTION: HEAT CAUSED BY CARELESS BUFFING WILL DESTROY RUBBER AND MAKE IT GUMMY.


8.2 R Pump - Frames 1&2
 Drawing #2115255



Ref.	Description	Ref.	Description	Ref.	Description
1211	Casing, Suctionside	3134	Support foot	4610.2	O-ring, thrust brg
1212	Casing, Glandside	3230	Thrust brg.Hsg.	4610.3	O-ring, Stuffing Box
1916.1	Liner-Suction	3260	Bearing cover	6541	Lockwasher
1916.2	Liner-Gland	3712	Bearing lock nut	6572.1	Stud, Gland
2110	Pump shaft	3856	Oil site gauge	6572.2	Stud, Liner
2200	Impeller	4100	Stuffing Box	6572.3	Stud, Liner/SB
2445	Shaft sleeve	4120	Gland	6578.1	Threaded plug, pipe
2460	Spacer, Impeller	4130	Packing	6578.2	Threaded plug, vent
2540	Deflector	4132	Stuffing box bushing, Protector plate	6580	Nut, wearplate
2542	Clamping ring	4134	Lantern Ring	6700.1	Key, coupling
3011	Radial ball bearing	4300.1	Radial lip seal, Line brg.	6700.2	Key, shaft
3031	Thrust bearing	4300.2	Radial lip seal, Thrust brg.	6810	Dowel Pin
3120	Bearing support, Pedestal	4590	Gasket-Impeller		
3130	Bearing bracket	4610.1	O-ring, Line brg.		


8.3 RX - Frames 1&2

Drawing #2119715




Ref.	Description	Ref.	Description	Ref.	Description
1211	Casing, Suctionside	3134	Support foot	4610.1	O-ring-Expeller WrPlt
1212	Casing, Glandside	3230	Thrust bearing housing	4610.2	O-ring (Line brg.)
1915	Expeller wearplate	3260	Bearing cover	4610.3	O-ring (thrust brg)
1916.1	Liner-Suction	3712	Bearing lock nut	6541	Lockwasher
1916.2	Liner-Gland	3856	Oil site gauge	6572.1	Stud, Gland
2110	Pump shaft	4100	Stuffing Box	6572.2	Stud, Liner
2200	Impeller	4110	Expeller Housing	6576	Adjusting Screw, fixture
2250	Expeller	4120	Gland	6578	Threaded plug, vent
2445	Shaft sleeve	4130	Packing	6580	Nut, wearplate
2460	Spacer, Impeller	4134	Lantern Ring	6700.1	Key, coupling
2540	Deflector	4300.1	Radial lip seal, Line brg.	6700.2	Key, shaft
2542	Clamping ring	4300.2	Radial lip seal, Thrust brg.	6810	Dowel Pin
3011	Radial ball bearing	4590.1	Gasket, Casing		
3031	Thrust bearing	4590.2	Gasket, Impeller		
3120	Bearing support, Pedestal	4590.3	Gasket, Sleeve		
3130	Bearing bracket	4590.4	Gasket, wearplate		

8.4 R pump - Frame 3&4
 Drawing #2116115



Ref.	Description	Ref.	Description	Ref.	Description
1211	Casing,Suctionside	3130	Bearing bracket	4300.2	Radial lip seal, Thrust brg.
1212	Casing, Glandside	3134	Support foot	4590.2	Gasket, Impeller
1916.1	Liner-Suction	3230	Thrust bearing housing	4590.4	Gasket, wearplate
1916.2	Liner-Gland	3260	Bearing cover	4610.2	O-ring (Line brg.)
2110	Pump shaft	3712	Bearing lock nut	4610.3	O-ring (thrust brg)
2200	Impeller	3856	Oil site gauge	6541	Lockwasher
2445	Shaft sleeve	4100	Stuffing Box	6572.1	Stud, Liner
2460	Spacer, Casing	4110	Expeller Housing	6572.2	Stud, Liner/SB
2540	Deflector	4120	Gland	6578	Threaded plug, vent
2542	Clamping ring	4130	Packing	6580	Nut
3011	Radial ball bearing	4132	Stuffing box bushing, Protector plate	6700.1	Key, coupling
3031	Thrust bearing	4134	Lantern Ring	6700.2	Key, shaft
3120	Bearing support, Pedestal	4300.1	Radial lip seal, Line brg.	6810	Dowel Pin

8.5 Frame 6 (18R416)
 Drawing #2118799



Ref.	Description
1211	Casing, Suction Side
1212	Casing, Gland Side
1916.1	Liner-suction side
1916.2	Liner-Gland Side
2110	Pump shaft
2200	Impeller
2445	Shaft sleeve
2460.1	Spacer, Impeller
2460.2	Spacer-Casing
2540.1	Deflector
2540.2	Deflector (optional)
2542	Clamping Ring
2912	Impeller Nut
3011	Radial ball bearing
3031	Thrust bearing
3110	Bearing bracket
3120	Bearing support pedestal
3230	Thrust bearing housing
3260	Bearing Cover
3712	Bearing lock nut
3840	Lubricating pipe
3856	Oil site gauge
4120	Gland
4130	Packing
4132	Stuffing Box Bushing
4134	Lantern Ring
4260	Spring
4300.1	Radial lip seal, Line brg.
4300.2	Radial lip seal, Thrust Brg.
4590.1	Gasket, Inboard Brg.
4590.2	Gasket, Outboard
4610.1	O-ring, shaft sleeve
6541	Lockwasher
6572	Stud, gland
6576	Adjusting screw
6578.1	Threaded plug, Pipe Plug
6578.2	Threaded plug, Vent Plug
6580	Nut, gland
6700.1	Key, coupling
6700.2	Key, shaft
6810	Dowel Pin

8.6 General arrangement drawing

The typical general arrangement drawing and any specific drawings required by the contract will be sent to the Purchaser separately unless the contract specifically calls for these to be included into the User Instructions. If required, copies of other drawings sent separately to the Purchaser should be obtained from the Purchaser and retained with these User Instructions.

9 CERTIFICATION

Certificates, determined from the contract requirements will be provided with this manual. Examples are certificates for CE marking and ATEX marking. If required, copies of other certificates sent separately to the Purchaser should be obtained from Purchaser for retention with the User Instructions. See section 1.9, *Noise level*, for details of typical noise certification.

10 OTHER RELEVANT DOCUMENTATION AND MANUALS

10.1 Supplementary User Instruction manuals

Supplementary instruction determined from the contract requirements for inclusion into User Instructions such as for a driver, instrumentation, controller, sub-driver, seals, sealant system, mounting component etc are included under this section. If further copies of these are required, they should be obtained from the purchaser for retention with these User Instructions.

Where any pre-printed set of User Instructions are used, and satisfactory quality can be maintained only

by avoiding copying these, they are included at the end of these User Instructions such as within a standard clear polymer software protection envelope.

10.2 Change notes

If any changes, agreed with Flowserve Pump Division, are made to the product after its supply, a record of the details should be maintained with these User Instructions.

10.3 Additional sources of information

Reference 1:

NPSH for Rotordynamic Pumps: a reference guide, Europump Guide No. 1, Europump & World Pumps, Elsevier Science, United Kingdom, 1999.

Reference 2:

Pumping Manual, 9th edition, T.C. Dickenson, Elsevier Advanced Technology, United Kingdom, 1995.

Reference 3:

Pump Handbook, 2nd edition, Igor J. Karassik et al, McGraw-Hill Inc., New York, 1993.

Reference 4:

ANSI/HI 1.1-1.5
Centrifugal Pumps - Nomenclature, Definitions, Application and Operation.

Reference 5:

ANSI B31.3 - Process Piping.

Your Flowserve factory contact:

**Flowserve Pump Division
5310 Taneytown Pike,
Taneytown,
Maryland,
USA 21787**

Telephone +1 (410) 756 2602
Fax +1 (410) 756 2615

In Europe:

Flowserve Sihi (Spain) S.L.
Vereda de los Zapateros C.P.28223
Pozuelo de Alarcon Madrid
Spain

Flowserve Sihi (Spain) S.L.
Avenida de Madrid 67 C.P. 28500
Arganda del Rey Madrid
Spain

Telephone +34 (0)91 709 1310
Fax +34 (0)91 715 9700

FLOWSERVE REGIONAL SALES OFFICES:

USA and Canada

Flowserve Corporation
5215 North O'Connor Blvd.,
Suite 2300
Irving, Texas 75039-5421, USA
Telephone +1 972 443 6500
Fax +1 972 443 6800

Europe, Middle East, Africa

Flowserve FSG – Italy
Worthing S.r.l.
Via Rossini 90/92
20033 Desio (Milan), Italy
Telephone +39 0362 6121
Fax +39 0362 628 882

Latin America and Caribbean

Flowserve Corporation
6840 Wynnwood Lane
Houston, Texas 77008, USA
Telephone +1 713 803 4434
Fax +1 713 803 4497

Asia Pacific

Flowserve Pte. Ltd
10 Tuas Loop
Singapore 637345
Telephone +65 6771 0600
Fax +65 6862 2329

Visit our web site at: www.flowserve.com